





## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
1	5140021-65	MACHINE SCREW	10
2	5140021-64	BUMPER	1
3	5140021-07	MACHINE SCREW	1
4	5140021-11	SPRING WASHER	1
5	5140021-08	SELF-TAP SCREW	2
6	5140020-38	MACHINE SCREW	1
7	5140020-39	SPRING,WASHER	1
8	5140024-18	TERMINAL	5
9	5140051-37	BRUSH HOLDER	2
10	5140020-43	SET SCREW	2
11	5140020-41	HOUSING ASSY.	1
13	5140020-50	BOLT	2
14	622608-00	NAME PLATE	1
15	622602-00	CAUTION LABEL	1
16	5140020-46	BRUSH CAP	2
17	5140020-26	BRUSH	2
18	622603-00	ID LABEL	1
19	5140021-78	MOLTO PRANE	1
20	5140020-28	CONTROLLER	1
21	5140021-49	SELF-TAP SCREW	1
22	5140021-50	LOCK NUT	1
23	5140020-23	MAGNET	1
24	5140020-25	LOCK WASHER	1
25	5140020-24	WASHER	5
26	5140003-46	BALL BEARING	1
27	5140020-44	LOCK,BEARING	1
28	5140020-21	FIELD ASSY.	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
29	5140020-22	TERMINAL,BRUSH	2
30	5140020-45	SELF-TAP SCREW	2
31	5140020-51	OIL SEAL	1
32	5140021-72	BALL BEARING	1
33	5140020-20	ARMATURE ASSY.	1
34	5140020-49	PIN	3
35	5140020-76	SET SCREW	1
36	5140051-44	COVER ASSEMBLY	1
37	5140020-48	SELF-TAP SCREW	3
38	622606-00	CAUTION LABEL	1
39	5140020-52	WORM	1
40	5140020-53	WASHER	2
41	5140020-54	LOCK NUT	1
42	5140020-55	OIL GAUGE	1
43	5140021-63	BUMPER	1
45	000000-00	No Longer Available	1
46	5140020-71	WASHER	1
47	5140020-70	SPRING,WASHER	9
48	5140020-69	BOLT	4
49	5140051-36	PLATE	1
51	5140021-59	MACHINE SCREW	1
52	5140051-38	CHAIN	1
53	5140020-60	KEY	1
54	5140020-57	SHAFT	1
55	5140020-65	OIL SEAL	1
56	5140020-64	NEEDLE BEARING	6
57	5140020-67	MACHINE SCREW	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
58	5140020-66	HOLDER	1
59	5140020-63	O-RING	1
60	5140021-73	BALL BEARING	1
61	5140020-58	RETAINING RING	1
62	5140020-59	GEAR	1
63	5140020-61	SPRING,WASHER	1
64	5140020-62	LOCK NUT	1
65	5140051-39	SPROCKET ASSY.	1
66	DW3983	18TPI BANDSAW BLD	1
69	5140020-82	WASHER	2
70	5140020-81	WASHER	2
71	5140020-72	WASHER	4
73	5140020-77	PULLEY	1
74	5140020-79	TIRE,RUBBER	2
75	5140020-80	BUSHING	3
77	5140051-40	SPROCKET ASSY.	1
78	5140020-68	PULLEY SHAFT	1
81	36480-98	CORD/10FT./18-3	1
82	5140020-67	MACHINE SCREW	2
84	5140020-94	HANDLE, SWITCH	1
85	053650-00	TERMINAL	1
86	5140021-04	CORD CLAMP	1
87	5140051-41	SCREW	2
88	5140020-27	SWITCH	1
90	5140021-02	SELF-TAP SCREW	1
91	5140020-96	GRIP PAD	1
92	5140021-00	SELF-TAP SCREW	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
93	5140021-06	SELF-TAP SCREW	2
94	5140020-95	HANDLE COVER	1
95	5140020-97	MACHINE SCREW	1
96	330005-01	PROTECTOR,CORD	1
97	5140021-61	CONNECTOR	3
98	5140021-62	CABLE TIE	4
99	5140020-35	TRANSFORMER	1
100	5140021-67	HOOK	1
103	330045-13	SCREW,TAPTITE	2
104	5140021-53	BLADE GUARD	1
105	5140021-56	SCREW	2
106	5140021-55	PLATE,GUIDE	1
107	5140021-57	NUT SQUARE	2
108	5140021-75	MACHINE SCREW	2
110	5140051-42	HOLDER	1
111	5140020-90	WASHER	6
112	5140021-76	ROLLER	8
115	5140020-89	PIN,BEARING	4
116	5140020-87	WASHER	5
117	5140021-77	ROLLER	2
118	5140020-88	PIN,BEARING	2
119	5140020-85	BEARING ASSEMBLY	1
126	5140021-32	PULLEY	1
128	5140021-28	SHAFT	1
129	5140021-14	NUT	1
130	5140021-12	ARM	1
131	5140021-13	SHAFT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
132	5140021-27	BOLT	2
133	5140021-17	SCREW	2
134	5140021-18	THRUST WASHER	2
137	5140021-23	WASHER	2
138	5140021-22	SPRING,TENSION	1
139	5140021-24	PIN	1
140	5140021-20	CAMSHAFT	1
141	5140021-38	HOLDER,BEARING	1
150	5140021-37	BEARING ASSEMBLY	1
151	5140021-79	VINYL TUBE	1
154	5140020-30	LAMP	1
155	5140020-31	LIGHT COVER	1
156	5140020-29	LIGHT	1
157	5140021-46	PLATE,SWITCH	1
158	5140020-32	SWITCH	1
160	622607-00	LABEL,SPEED	1
161	5140020-34	KNOB	1
162	5140020-33	POTENTIOMETER	1
163	5140021-47	MACHINE SCREW	3
164	5140021-82	SET SCREW	1
165	5140021-54	ROLL PIN	1
166	5140021-83	ROLLER	1
170	5140021-51	HANDLE,FRONT	1
171	5140021-52	MACHINE SCREW	2
172	5140021-84	PULLEY GUARD	1
174	5140021-85	BOLT	1
175	5140021-21	ROLL PIN	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
176	5140021-19	LEVER,TENSION	1
501	98000-09	WRENCH,HEX-4MM	1
800	449562-01	LUBRICANT-6 OZ.	1
800	286445-00	GREASE.14 OZ.	1
800	5140021-86	OIL	1
861	000000-00	No Longer Available	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.



## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
1	5140021-65	MACHINE SCREW	10
2	5140021-64	BUMPER	1
3	5140021-07	MACHINE SCREW	1
4	5140021-11	SPRING WASHER	1
5	5140021-08	SELF-TAP SCREW	2
6	5140020-38	MACHINE SCREW	1
7	5140020-39	SPRING,WASHER	1
8	5140024-18	TERMINAL	5
9	5140051-37	BRUSH HOLDER	2
10	5140020-43	SET SCREW	2
11	5140020-41	HOUSING ASSY.	1
13	5140020-50	BOLT	2
14	622608-00	NAME PLATE	1
15	622602-00	CAUTION LABEL	1
16	5140020-46	BRUSH CAP	2
17	5140020-26	BRUSH	2
18	622603-00	ID LABEL	1
19	5140021-78	MOLTO PRANE	1
20	5140020-28	CONTROLLER	1
21	5140021-49	SELF-TAP SCREW	1
22	5140021-50	LOCK NUT	1
23	5140020-23	MAGNET	1
24	5140020-25	LOCK WASHER	1
25	5140020-24	WASHER	5
26	5140003-46	BALL BEARING	1
27	5140020-44	LOCK,BEARING	1
28	5140020-21	FIELD ASSY.	1

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
29	5140020-22	TERMINAL,BRUSH	2
30	5140020-45	SELF-TAP SCREW	2
31	5140020-51	OIL SEAL	1
32	5140021-72	BALL BEARING	1
33	5140020-20	ARMATURE ASSY.	1
34	5140020-49	PIN	3
35	5140020-76	SET SCREW	1
36	5140051-44	COVER ASSEMBLY	1
37	5140020-48	SELF-TAP SCREW	3
38	622606-00	CAUTION LABEL	1
39	5140020-52	WORM	1
40	5140020-53	WASHER	2
41	5140020-54	LOCK NUT	1
42	5140020-55	OIL GAUGE	1
43	5140021-63	BUMPER	1
45	000000-00	No Longer Available	1
46	5140020-71	WASHER	1
47	5140020-70	SPRING,WASHER	9
48	5140020-69	BOLT	4
49	5140051-36	PLATE	1
51	5140021-59	MACHINE SCREW	1
52	5140051-38	CHAIN	1
53	5140020-60	KEY	1
54	5140020-57	SHAFT	1
55	5140020-65	OIL SEAL	1
56	5140020-64	NEEDLE BEARING	6
57	5140020-67	MACHINE SCREW	2

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
58	5140020-66	HOLDER	1
59	5140020-63	O-RING	1
60	5140021-73	BALL BEARING	1
61	5140020-58	RETAINING RING	1
62	5140020-59	GEAR	1
63	5140020-61	SPRING,WASHER	1
64	5140020-62	LOCK NUT	1
65	5140051-39	SPROCKET ASSY.	1
66	DW3983	18TPI BANDSAW BLD	1
69	5140020-82	WASHER	2
70	5140020-81	WASHER	2
71	5140020-72	WASHER	4
73	5140020-77	PULLEY	1
74	5140020-79	TIRE,RUBBER	2
75	5140020-80	BUSHING	3
77	5140051-40	SPROCKET ASSY.	1
78	5140020-68	PULLEY SHAFT	1
81	36480-98	CORD/10FT./18-3	1
82	5140020-67	MACHINE SCREW	2
84	5140020-94	HANDLE, SWITCH	1
85	053650-00	TERMINAL	1
86	5140021-04	CORD CLAMP	1
87	5140051-41	SCREW	2
88	5140020-27	SWITCH	1
90	5140021-02	SELF-TAP SCREW	1
91	5140020-96	GRIP PAD	1
92	5140021-00	SELF-TAP SCREW	2

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
93	5140021-06	SELF-TAP SCREW	2
94	5140020-95	HANDLE COVER	1
95	5140020-97	MACHINE SCREW	1
96	330005-01	PROTECTOR,CORD	1
97	5140021-61	CONNECTOR	3
98	5140021-62	CABLE TIE	4
99	5140020-35	TRANSFORMER	1
100	5140021-67	HOOK	1
103	330045-13	SCREW,TAPTITE	2
104	5140021-53	BLADE GUARD	1
105	5140021-56	SCREW	2
106	5140021-55	PLATE,GUIDE	1
107	5140021-57	NUT SQUARE	2
108	5140021-75	MACHINE SCREW	2
110	5140051-42	HOLDER	1
111	5140020-90	WASHER	6
112	5140021-76	ROLLER	8
115	5140020-89	PIN,BEARING	4
116	5140020-87	WASHER	5
117	5140021-77	ROLLER	2
118	5140020-88	PIN,BEARING	2
119	5140020-85	BEARING ASSEMBLY	1
126	5140021-32	PULLEY	1
128	5140021-28	SHAFT	1
129	5140021-14	NUT	1
130	5140021-12	ARM	1
131	5140021-13	SHAFT	1

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
132	5140021-27	BOLT	2
133	5140021-17	SCREW	2
134	5140021-18	THRUST WASHER	2
137	5140021-23	WASHER	2
138	5140021-22	SPRING,TENSION	1
139	5140021-24	PIN	1
140	5140021-20	CAMSHAFT	1
141	5140021-38	HOLDER,BEARING	1
150	5140021-37	BEARING ASSEMBLY	1
151	5140021-79	VINYL TUBE	1
154	5140020-30	LAMP	1
155	5140020-31	LIGHT COVER	1
156	5140020-29	LIGHT	1
157	5140021-46	PLATE,SWITCH	1
158	5140020-32	SWITCH	1
160	622607-00	LABEL,SPEED	1
161	5140020-34	KNOB	1
162	5140020-33	POTENTIOMETER	1
163	5140021-47	MACHINE SCREW	3
164	5140021-82	SET SCREW	1
165	5140021-54	ROLL PIN	1
166	5140021-83	ROLLER	1
170	5140021-51	HANDLE,FRONT	1
171	5140021-52	MACHINE SCREW	2
172	5140021-84	PULLEY GUARD	1
174	5140021-85	BOLT	1
175	5140021-21	ROLL PIN	1

## Parts List for D28770 Type 1

Item Number	Part Number	Description	Qty Required
176	5140021-19	LEVER,TENSION	1
501	98000-09	WRENCH,HEX-4MM	1
800	449562-01	LUBRICANT-6 OZ.	1
800	286445-00	GREASE.14 OZ.	1
800	5140021-86	OIL	1
861	000000-00	No Longer Available	1