



Model DC18RE Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	812P95-5	MAKITA LOGO LABEL	1
002	812P94-7	CHARGING CONDITION LABEL	1
003	457693-8	LENS	2
004	144562-9	CHARGER CASE COMPLETE	1
	D10	INC. 3	
005	457692-0	TERMINAL COVER	1
006	231474-6	COMPRESSION SPRING 4	2 PC.
007	266278-7	TAPPING SCREW FLANGE BT3X10	1 PC.
008	632K43-6	TERMINAL UNIT	1
009	638499-5	SCIROCCO FAN	2 PC.
010	233194-8	COMPRESSION SPRING 4	1 PC.
011	457691-2	TERMINAL BASE	1
012	266764-8	TAPPING SCREW 3X8	4 PC.
013	667982-5	VINYL CORD #18-2-2.0	1 PC.
014	620692-5	LED CIRCUIT	1
015	266764-8	TAPPING SCREW 3X8	3 PC.
016	652802-6	FUSE	1 PC.
017	647306-1	VARISTOR	1 PC.
018	620681-0	CHARGING CIRCUIT	1
	D10	INC. 16,17	
019	457690-4	CHARGER CASE COVER	1
021	286255-3	CAP 13	4 PC.
022	266426-8	TAPPING SCREW 4X20	4 PC.
E01	812P96-3	CAUTION LABEL	1