



## Parts List for DC740KA-B3 Type 2

Item Number	Part Number	Description	Qty Required
1	649284-00	HOUSING & COVER	1
2	389080-00	BUTTON(FWD/REV)	1
3	389081-01	TERMINAL BOARD	1
4	391092-00SV	LEAD-RED	1
5	391091-00SV	LEAD-BLACK	1
6	682211-00	SCREW,TORX	14
7	391996-00	SHIFTER ASSY.	1
8	631445-00	MOTOR & PINION	1
11	330075-87	CHUCK	1
12	638563-00	TRANSMISSION ASSY.	1
13	149518-01	SCREW	1
14	152274-28	VSR SWITCH (DC)	1
15	395657-00	ID LABEL	1
16	148354-03	BIT CLIP	1
17	607918-41	SCREWDRIVER BIT	1
20	562160-01	SCREW	2
21	658926-00	NAME PLATE	1
22	389083-00	PLATE	1
861	389108-02	KITBOX	1
866	388683-12	1 HOUR CHARGER	1
867	DE9074	12V BATTERY	2