



Parts List for DC750-AR Type 2

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|--------------------|--------------|
| 1 | 649284-01 | CLAMSHELL SET | 1 |
| 2 | 389080-00 | BUTTON(FWD/REV) | 1 |
| 3 | 389081-01 | TERMINAL BOARD | 1 |
| 4 | 391092-00SV | LEAD-RED | 1 |
| 5 | 391091-00SV | LEAD-BLACK | 1 |
| 6 | 682211-00 | SCREW,TORX | 14 |
| 7 | 391996-00 | SHIFTER ASSY. | 1 |
| 8 | 631445-01SV | MOTOR & PINION | 1 |
| 9 | 389103-00 | WASHER | 1 |
| 11 | 330075-87 | CHUCK | 1 |
| 12 | 638563-01 | TRANSMISSION ASSY. | 1 |
| 13 | 149518-01 | SCREW | 1 |
| 14 | 152274-28 | VSR SWITCH (DC) | 1 |
| 15 | 395657-00 | ID LABEL | 1 |
| 16 | 148354-03 | BIT CLIP | 1 |
| 17 | 607918-41 | SCREWDRIVER BIT | 1 |
| 20 | 562160-01 | SCREW | 2 |
| 21 | 658927-00 | NAMEPLATE | 1 |
| 22 | 389083-00 | PLATE | 1 |
| 866 | DE9062 | 9.6V BATTERY | 1 |