



DATE CODE

15

70

71

60

61

4

19

24

13

8

33

34

33

32

13

6

55

53

54

3

9

31

30

8

Parts List for DCD470X1 Type 1

Item Number	Part Number	Description	Qty Required
1	N526649	HOUSINGS	1
2	N657910	GEARCASE ASSY	1
3	N508751	FWD/REV BUTTON	1
4	N657924	MODULE & STATOR ASSY	1
5	N657904	OUTPUT SPINDLE	1
6	N657938	CHUCK KEY HOLDER	1
7	N565055	RETAINING RING	1
8	330021-11	STOP NUT	3
9	N576469	MACHINE SCREW	3
11	N514195	TOP HANDLE	1
13	N394333	LENS	2
15	330019-04	SCREW,PLASTITE	7
16	330019-74	SCREW	4
17	N602376	SCREW	7
18	N561739	SCREW	2
19	N467560	PLATE	1
20	N527895	BOOT	1
21	N690172	CHUCK PKG.	1
24	N551177	CHUCK KEY	1
30	N565302	RELEASE BUTTON	1
31	1008957-00	SPRING	2
32	N565300	SHIFT KNOB	1
33	N677397	SEAL PLATE	2
34	N677396	FELT SEAL	1
35	N565023	SPRING	2
36	N560945	CRADLE	1
37	N561503	RETAINING RING	1

Parts List for DCD470X1 Type 1

Item Number	Part Number	Description	Qty Required
38	N564483	CAMSHAFT ASSEMBLY	1
39	N561479	O-RING	1
40	330041-09	PIN	1
42	N657906	PINION SHAFT ASSY	1
43	N517599	BEARING PLATE	1
44	N544267	WASHER	1
45	N657913	CLUTCH ASSEMBLY	1
46	N507315	HUB	1
47	N507317	SHIFT RING	1
48	N657912	GEAR	1
49	N514628	WASHER	1
50	N657911	GEAR SHAFT ASSEMBLY	1
51	N533213	SHIFTER ROD	2
52	N657934	SHIFT FORK	1
53	330019-08	SCREW	4
54	N657914	ROTOR ASSY.	1
55	N528987	BAFFLE	1
60	N091479	MOUNT- SPRING	1
61	N461735	SPRING	1
70	N594937	RATING LABEL	1
71	N595231	LABEL	1
80	N657940	SIDE HANDLE ASSEMBLY	1
800	286436-00	GREASE, 500GRAMS	1
862	N594987	TOOL BAG	1
866	DCB609	FLEXVOLT BATTERY	1
867	N475920	BATTERY CAP	1
871	DCB118	CHARGER	1