

















Parts Breakdown

DCS340

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	021-131-110	QUAD PORT CYLINDER, DCS340	1
2	001-151-670	ANGULAR NIPPLE,DCS340	1
3	965-524-042	GASKET, DCS341	1
4	021-132-110	PISTON ASS'Y, DCS341	1
5	021-132-230	PISTON RING, DCS430	1
6	021-132-020	PISTON PIN, DCS340	1
7	108-132-050	SPRING RING, DCS340	2
8	957-120-028	CRANKSHAFT CPL., DCS341	1
9	021-123-010	CON-ROD CPL.,DCS340	1
10	962-640-061	ROLLER 4X6, DCS340	12
11	939-615-260	KEY, DCS340	1
12	920-108-044	HEXAGONAL NUT,DCS340	1
13	108-121-010	STOP DISC, DCS340	2
14	965-524-011	GASKET, DCS330S	1
15	028-111-640	CRANKCASE, DCS341	1
16	936-430-160	SPIRAL PIN 3X16, DCS340	2
17	965-403-490	RUBBER BUFFER, DCS341	3
18	962-300-011	NEEDLE BUSH, DCS340	1
19	929-319-101	SNAP RING 19X1, DCS340	1
20	962-900-049	RADIAL RING, DCS330S, T1	1
21	965-450-040	OIL TANK PLUG ASSY, DCS400	1
22	963-100-041	GASKET, OIL CAP, DCS340	1
23	028-111-630	CRANKCASE, DCS341	1
24	010-245-010	VENT VALVE, DCS431	1
25	021-245-070	GUIDE PIN, DCS340	1
26	905-808-254	FAST BOLT M8X25, DCS340	1
27	908-005-305	TORX SCREW 5X30, DCS340	6
28	001-213-042	NUT WITH PIVOT, DCS341	1
29	389-213-080	STRAINING SCREW, DCS340	1
30	957-250-015	SPIKE BAR ASS'Y, DCS341	1
31	908-105-124	C. SCREW M5X12,DCS340	2
32	908-405-255	SCREW M5X25, DCS340	4
33	028-142-021	IGNITION ELECTRONIC, DCS341	1
34	028-147-000	S.CIRCUIT CABLE,DCS340	1
35	970-310-200	IGNITION CABLE(150 MM), DCS340	1
36	970-502-110	INSULATING HOSE (43 MM), DCS340	1
37	957-604-260	PLUG CAP ASSY, DCS431	1
38	965-604-180	SPRING, DCS431	1
39	965-603-018	SPARK PLUG, BPMR6F, DCS340	1
40	908-605-145	F.H. SCREW M5X14, DCS9000	2
41	965-404-031	STARTER GRIP, DCS340	1
42	900-004-375	DISC SPACER, DCS340	1
43	021-160-000	STARTER ASS'Y, DCS340	1
43	021160001	N/A	1
44	985-000-150	STARTER ROPE 3.0MM 100M, DCS330S	1
45	028-166-030	STARTER SPRING, DCS340	1
46	021-166-040	SNAP RING, DCS340	1
47	021-141-011	FLYWHEEL	1
48	928-308-001	SPRING WASHER , DCS340	1
49	920-308-024	HEX NUT M8X1, DCS340	1
50	028-112-630	FAN HOUSING, DCS341	1
51	908-005-165	HEAD SCREW M5X16, DCS340	3
52	028-213-615	HAND PROTECT, DCS341	1
53	980-114-237	LABEL (SAFETY), DCS430	1
54	028-213-560	SPRING, DCS341	1
55	028-213-670	SPROCKET GUARD ASS'Y, DCS341	1
56	028-213-501	BRAKE SPRING, DCS341	1
57	980-114-251	LABEL, DCS341	1
58	923-208-004	HEX NUT, DCS341	1
59	021-245-003	OIL PUMP CPL.,UC3500, UC4000	1
60	965-451-962	SUCTION LINE ASSY, DCS340	1
61	021-245-040	WORM, DCS340	1
62	021-245-080	SEALING CAP, DCS340	1
63	021-111-037	GUIDE PLATE, DCS340	1



Parts Breakdown

DCS340

64	021-224-010	DISC, DCS340	1
65	028-223-060	CLUTCH DRUM CPL, DCS340	1
65	028-223-311	CLUTCH DRUM CPL.3/8,DCS340	1
66	021-180-011	CLUTCH ASSY,DCS340	1
67	028-184-020	FLAT SPRING,DCS340	2
69	908-205-605	LENS HEAD SCREW, DCS340	2
70	928-405-000	WASHER, DCS340	2
71	021-174-111	HEAT SHIELD, PS401	1
72	021-174-321	MUFFLER, DCS330S	1
73	021-174-340	SPARK SCREEN,DCS340	1
74	915-135-100	SCREW 3.5X9.5, DCS431	1
75	965-524-062	GASKET, DCS341	1
76	028-118-050	COVER ASS'Y, PS401	1
77	028-118-180	INSERT, DCS400	1
78	001-118-062	NUT M5,DCS340	2
79	028-173-041	AIR FILTER,NYLON, PS401	1
81	908-205-605	LENS HEAD SCREW, DCS340	1
82	028-118-310	CYLINDER HOOD, DCS340	1
83	908-005-165	HEAD SCREW M5X16, DCS340	1
84	028-310-050	TUBULAR HANDLE, DCS330S	1
85	913-455-454	F. SCREW M5.5X45, DCS341	1
86	028-114-691	TANK ASS'Y DCS341	1
87	965-404-661	FUEL LINE, DCS341	1
88	937-130-120	RIVET, PS401	1
89	957-114-010	VENT VALVE ASS'Y, DCS6000I21	1
90	028-117-244	THROTTLE LINKAGE, DCS341	1
91	965-403-490	RUBBER BUFFER, DCS341	1
92	913-455-204	SCREW M5.5X20, DCS6800I	1
93	021-114-051	FIXING BUSH, DCS431	3
94	908-005-305	TORX SCREW 5X30, DCS340	1
95	913-455-304	SCREW M5.5X30, DCS6000I21	2
96	980-003-583	CABLE STRAP, DCS341	1
97	963-601-130	SUCTION HEAD, DPC6400	1
98	010-114-050	OIL TANK PLUG, COMP., DCS9000	1
99	963-228-030	GASKET, DCS9000	1
100	920-205-000	HEX NUT M5, DCS340	2
101	965-524-120	GASKET, DCS340	1
102	965-452-060	VENTILATION LINE, DCS9000	1
103	970-502-110	INSULATING HOSE (43 MM), DCS340	1
104	965-524-092	GASKET, DCS341	1
105	965-524-131	GASKET, DCS341	1
106	028-131-061	INTERMED.FLANGE, DCS340	1
107	965-524-082	GASKET, DCS341	1
108	028-118-271	BOTTOM, PS401	1
109	965-404-430	GASKET, DCS340	1
110	900-205-554	HEX SCREW M5X55, DCS340	2
111	908-005-305	TORX SCREW 5X30, DCS340	2
112	028-150-750	CHOKE LINKAGE, DCS340	1
113	028-150-740	CHOKE LEVER,DCS340	1
114	028-118-121	STOP SWITCH, DCS341	1
115	965-404-421	GASKET, DCS340	1
116	028-118-160	PLATE, DCS340	1
117	028-118-112	CONTACT PLATE, DCS340	1
118	908-005-165	HEAD SCREW M5X16, DCS340	1
119	028-151-710	CARBURETOR, DCS-401	1
120	118-151-190	SCREW, DCS340	1
121	001-151-140	PUMP COVER,DCS340	1
122	021-151-240	ADJUSTING SCREW, DCS340	1
123	021-151-230	PRESSURE SPRING, DCS340	1
124	021-151-540	GASKET SET, DCS340	1
125	021-151-180	SCREEN, DCS340	1
126	108-151-320	THROTTLE SHUTTER,DCS340	1
127	118-151-060	SCREW, DCS340	1
128	108-151-350	SAFETY WASHER, DPC7331	1
129	118-151-020	SCREW, DCS340	1
130	001-151-255	CHOKE SHAFT, DCS340	1
131	001-151-320	THROTTLE SHAFT, DCS341	1



Parts Breakdown

DCS340

132	001-151-310	SPRING, DCS340	1
133	021-151-480	SPRING, DCS340	1
134	021-151-530	SPRING, DCS340	1
135	118-151-160	FRICITION SPRING,DPC7331	1
136	118-151-170	FRICITION BALL, DPC7331	1
137	118-151-060	SCREW, DCS340	1
138	001-151-350	CHOKE SHUTTER (62-175), EHW120	1
139	957-150-040	CTRL.PARTS(CARB.),DCS340	1
141	021-151-120	DIAPHRAGM COVER, DCS340	1
142	118-151-020	SCREW, DCS340	1
144	021-151-470	IDLE ADJ.SCREW, DCS340	1
145	001-151-515	MAIN ADJ.SCREW, DCS340	1
146	952100633	CHAIN PROTECT COVER, DCS340	1
147	528092646	N/A	1
147	528092652	14 CHAIN, DCS34 & UC3530A	1
147	528092656	16 SAW CHAIN, UC4000	1
150	442030661	N/A	1
150	442035661	GUIDE BAR 14, DCS34 & UC3530A	1
150	442040661	16 GUIDE BAR, DCS34-16	1