



## Parts List for DCS380P1 Type 2

Item Number	Part Number	Description	Qty Required
1	613138-00SV	GEAR CASE ASSY.	1
2	N415904	ARMATURE & BRGS	1
3	142940-00	SCREW	2
4	N340319	FAN BAFFLE	1
5	613619-00	SCREW,THD.FORM	6
6	N436044	MAGNET RING	1
7	N412223	BRUSH HOLDER ASSY	1
8	N389143	THREAD FORMING SCREW	1
9	330045-06	SCREW	3
10	615940-00SV	GEAR & SPINDLE	1
11	619618-00	WAVY WASHER	1
12	622484-00	FLAT HD SCREW	3
13	621173-00	SUPPORT PLATE	1
14	N027851SV	GEARCASE COVER	1
15	621979-00	WEAR STRIP	2
16	618733-00	SHAFT SEAL	1
17	618477-00	FELT SEAL	1
18	N020720	SEAL PLATE	1
19	330045-43	SCREW,TAPTITE	1
20	N026647	SHAFT SERVICE KIT	1
21	000903-00	BALL	1
22	622647-00	SLIDER	1
22	N252639	SLIDER	1
23	622659-00	TORSION SPRING	1
23	N426742	SPRING	1
24	658115-00	YOKE CHANNEL	1
25	617000-00	SADDLE	1

## Parts List for DCS380P1 Type 2

Item Number	Part Number	Description	Qty Required
26	622486-00	FLAT HD SCREW	2
27	N063272	GASKET	1
28	N021857	BEARING	1
29	622485-00	LOCKNUT	2
30	621927-00	COVER	2
32	N264499	MOTOR HOUSING	1
33	330019-45	SCREW	4
34	N084697	BOOT	1
35	N088811	LEVER, BLADELOCK	1
37	617008-00	BRACKET	1
38	623511-00SV	SHOE ASSEMBLY	1
39	N347382	CLAMSHELL SET	1
40	330019-04	SCREW, PLASTITE	6
41	682211-00	SCREW PLASTITE	1
42	N413815	ELEC CONTROL ASSY	1
43	N102647	SPRING	1
44	N091479	MOUNT- SPRING	1
45	N060864	LOCK-OFF BUTTON	1
46	N408170	RATING LABEL	1
47	N093226	LABEL, IDENT	1
48	613619-02	THREAD FORMING SCREW	2
49	615983-00	LOCK PIN	1
50	617733-00	CAP	1
51	618427-00	SPRING	1
52	N330639	BALL BEARING	1
53	330003-64	BALL BEARING	1
54	696060-00	SNAP RING	1

## Parts List for DCS380P1 Type 2

Item Number	Part Number	Description	Qty Required
55	N275679	FELT SEAL	1
73	N105032	WARNING LABEL	1
800	286436-00	GREASE, 500GRAMS	1
861	N152704	KITBOX	1
866	DCB205	BATTERY PACK	1
871	DCB115	CHARGER	1