



## Parts List for DCS690X2 Type 1

Item Number	Part Number	Description	Qty Required
1	N484490	HOUSING	1
2	N484489	INTERMEDIATE PLATE	1
3	N520758	LED ASSY	1
5	N500094	LOCK OFF BUTTON	1
6	N484488	BATTERY DOOR	1
7	N648291	LATCH ASSEMBLY	1
8	N607141	PLUG ASSY	1
9	N607143	PLUG COVER	1
10	N569169	VALVE ASSEMBLY	1
11	N569170	HOSE ASSEMBLY	1
13	N513083	COVER	1
14	N588277	GUARD LEVER	1
15	N517849	EXTENSION SPRING	1
16	N648295	GEAR CASE COVER	1
17	N603098	BAFFLE,GUARD	1
19	N503701	GUARD	1
20	N563782	SCREW	2
21	N518761	PLATE	1
22	N648296	FITTING	1
23	N648299	FITTING	1
24	N569174	HOSE ASSEMBLY	1
26	N569324	HANDLE	1
28	N510353	SHOE	1
29	N493800	AUXILIARY HANDLE	1
30	N569343	CLAMP WASHER	1
33	145344-00	SCREW,SPECIAL	1
34	N420180	WRENCH	1

## Parts List for DCS690X2 Type 1

Item Number	Part Number	Description	Qty Required
35	N087259	DETENT SPRING	1
36	N516892	DETENT SPRING	2
37	N563689	FLAT HEAD SCREW	4
38	330019-02	SCREW,PLASTITE	2
39	330019-04	SCREW,PLASTITE	14
40	330019-07	SCREW,THD.FORM	3
41	N582524	SHOULDER SCREW	6
42	N563581	SCREW,PLASTITE	12
43	N569458	FLAT HEAD SCREW	4
44	N535932	SHOULDER SCREW	1
45	N530697	RATING LABEL	1
48	N575267	WARNING LABEL	1
49	N587383	WARNING LABEL	1
50	N569131	GEAR CASE ASSY.	1
51	N648306	GEAR CASE COVER	1
52	N569132	ROTOR ASSY.	1
53	N569142	MODULE & STATOR ASSY	1
54	N587679	KNOB ASSEMBLY	1
55	N569172	PARTS KIT	1
56	N648414	SPIDER	1
856	N499690	QUICK CONNECT	1
866	DCB609	FLEXVOLT BATTERY	1
867	N475920	BATTERY CAP	2
871	DCB118	CHARGER	1