



## Parts List for DDF212035P Type 0

Item Number	Part Number	Description	Qty Required
1	52166-PWR	STABILIZER	1
2	52110-PWR	BASEPLATE	1
3	52120-PWR	SHEAR CLP P3500 P35S	1
4	52108-PWR	GUIDE 2 / F-3 P3500	1
5	52102-PWR	PISTON FLAT END	1
5	52100-PWR	PISTON 2/DN-1 P3500	1
6	52106-PWR	PISTON RING	1
7	52160-PWR	PISTON GUIDE	1
11	52112-PWR	PISTON STOP P3500	1
12	52162-PWR	STEEL LINER ASSY	1
13	52152-PWR	PRESSURE PIN	1
14	52158-PWR	FRNT CAPSCR (2)	1
15	52122-PWR	STEEL ANNULAR BALL	1
16	52136-PWR	ANN BALL SPRING	1
17	52140-PWR	PRES BALL&SPR	1
19	DDF2221000-PWR	HOUSING	1
27	52128-PWR	THREAD PIN P/PA3500	1
28	52146-PWR	SEAR P3500 P35S	1
29	52134-PWR	SEAR SPRING	1
30	52178-PWR	SPRING GUIDE	1
31	52181-PWR	FIRING PIN ASSEMBLY	1
32	52180-PWR	SPRING DETENT	1
33	52181-PWR	FIRING PIN ASSEMBLY	1
34	52156-PWR	FIRING PINNUT	1
35	52172-PWR	RET RING P3500 P35S	1
36	52130-PWR	ADV LEVER P3500 P35S	1
37	52142-PWR	ADV LEV SPR	1

## Parts List for DDF212035P Type 0

Item Number	Part Number	Description	Qty Required
38	52118-PWR	TRIGGER P3500 P35S	1
39	52176-PWR	ADV LEV BUSHING	1
40	52132-PWR	ADV LEV GUIDE	1
41	52144-PWR	REAR SPR KIT	1
43	52150-PWR	END CAP P3500 P35S	1
44	52124-PWR	REL LEV PIN	1
45	52182-PWR	CHEESE HD SCRW (2)	2
46	52170-PWR	RELEASE LEVER	1
47	52174-PWR	TRIG RET SPRG	1
48	52154-PWR	COMPR SPRING	1
49	52168-PWR	SUPPORT STR ASSY	1
50	52184-PWR	HANDLE ALL SCRW	1
51	52186-PWR	RUBBER GRIP	1
52	52116-PWR	BASEPLTE 2/S14-1LIM	1
53	52114-PWR	GUIDE 2/F-4 LIM	1
54	52181-PWR	FIRING PIN ASSEMBLY	1
55	52126-PWR	LEVGUIDEKIT	1
56	52187-PWR	RUBBER GRIP ASSEMBLY	1
836	N411209	STEEL PLATE	1
856	52070-PWR	CLEANING KIT	1
856	50066-PWR	DIELECTRIC POLE TOOL	1
856	50065-PWR	DIELECTRIC POLE TOOL	1