















Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
1	5140001-79	FRAME	1
2	5140005-78	FRAME	1
3	000000-00	No Longer Available	1
4	645060-00	BOLT	4
5	429978-05	WASHER	4
6	429978-06	WHEEL SHAFT	1
7	429978-07	HEX HEAD BOLT	14
8	647128-00	WASHER	2
9	647122-00	WHEEL	2
10	647129-00	WASHER	2
11	647151-00	COTTER PIN	2
12	648587-00	FOOT	2
13	429978-13	ISOLATOR	6
14	429978-14	HEX HEAD BOLT	2
15	429978-15	HEX NUT	8
17	000000-00	No Longer Available	4
18	429985-03	COMP. FRONT BAR	1
19	429978-19	HEX HEAD BOLT	3
20	647154-00	L. HANDLE CLAMP	1
21	647125-00	HANDLE GRIP	2
22	647734-00	LEFT HANDLE	1
23	647734-00	LEFT HANDLE	1
24	5140001-76	WIRE HARNESS	1
25	429978-25	HANDLE CAP	2
26	647735-00	RIGHT HANDLE	1
27	647735-00	RIGHT HANDLE	1
28	647127-00	R. HANDLE CLAMP	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
29	641758-00	ASSY SKYHOOK PAINTED	1
30	647124-00	BRACKET	2
31	429978-31	COLLER	3
32	429978-32	GROMMET	3
33	429978-33	HEX HEAD BOLT	11
34	429978-34	WASHER	3
35	429978-35	COMPLETE CORD	1
36	429978-36	MUFFLER COVER	1
37	429978-37	WRENCH	1
38	000000-00	No Longer Available	2
39	000000-00	No Longer Available	1
40	429978-40	FUEL FILTER	1
41	429978-41	TANK CAP	1
42	429978-42	TANK GAUGE	1
43	429978-43	SCREW	2
44	429978-44	FUEL VALVE	1
45	429978-45	TANK	1
46	429978-46	GROMMET	2
47	429978-47	HEX HEAD BOLT	2
48	429978-48	WASHER	2
49	429978-49	COLLER	2
50	429978-50	GROMMET	2
51	429978-51	LABEL	2
52	000000-00	No Longer Available	1
53	000000-00	No Longer Available	1
54	647160-00	BOLT	8
55	5140004-82	WING NUT	2

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
56	5140004-83	PLATE	1
57	5140004-84	BOLT	2
58	5140004-85	FRAME	1
59	5140004-86	FRAME	1
60	5140004-87	SUPPORT PLATE	1
61	5140004-88	BATTERY COVER	1
62	5140004-89	CABLE	1
63	5140004-90	CABLE	1
64	000000-00	No Longer Available	1
65	285801-40	HOSE	1
103	000000-00	No Longer Available	1
104	429979-04	SWITCH	1
105	429979-05	THERMAL BREAKER	2
106	Z-D21508	BREAKER CIRCUIT125/2	1
106	429979-06	THERMAL BREAKER	2
107	429979-07	SELECT SWITCH	1
108	641521-01	CIRCUIT BREAKER	1
109	GS-0767	RECTIFIER	1
110	429979-10	IDLE CONTROL UNIT	1
111	GS-0480	RECEPTACLE 125V 20A	1
111	GS-0021	RECEPTACLE 125V 30A	2
112	GS-0644	RECEPTACLE GFCI 120V	2
113	429985-06	RECEPTACLE	1
114	429985-07	PLATE	1
115	429979-15	HEX NUT	12
116	429979-16	HEX NUT	1
117	000000-00	No Longer Available	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
118	429979-18	SCREW W/WASHER	2
119	643315-00	BOLT	1
120	000000-00	No Longer Available	1
121	643316-00	NUT	1
122	643317-00	WINGNUT	1
123	429979-23	LOGO PLATE	1
124	000000-00	No Longer Available	4
125	5140004-95	LABEL	1
126	429979-26	LABEL	1
127	429985-08	LABEL	1
128	429979-28	LABEL	1
129	429979-29	LABEL	1
130	000000-00	No Longer Available	1
131	429985-10	WIRE HARNESS	1
132	5140004-97	WIRE HARNESS	1
133	000000-00	No Longer Available	1
134	429979-34	COMPLETE CORD	1
135	429979-35	COMPLETE CORD	1
136	429985-11	WIRE HARNESS	1
137	429979-37	COMPLETE CORD	1
138	429979-38	COMPLETE CORD	1
139	429985-12	COMPLETE CORD	1
140	429979-40	COMPLETE CORD	1
141	000000-00	No Longer Available	1
148	429979-48	CAPACITOR	2
149	429979-49	COMPLETE CORD	1
150	5140012-48	LABEL	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
151	429979-51	HEX HEAD BOLT	2
152	429979-52	HEX HEAD BOLT	1
153	429978-19	HEX HEAD BOLT	1
154	5140004-98	FUSE	1
155	5140004-99	RECTIFIER	1
156	5140004-92	SWITCH	1
157	5140004-93	HANDLE	1
158	5140004-94	SCREW	1
159	000000-00	No Longer Available	1
221	429985-14	FRONT COVER	1
222	SSF-577	SCREW .375-16X1.00 H	4
223	429985-15	COMPLETE ROTOR	1
224	429982-04	BALL BEARING	1
225	000000-00	No Longer Available	1
226	000000-00	No Longer Available	2
227	429985-17	BOLT	1
228	000000-00	No Longer Available	1
229	429985-19	STATOR	1
230	429985-20	REAR COVER	1
231	429985-21	BOLT	4
232	000000-00	No Longer Available	1
233	000000-00	No Longer Available	2
234	429982-14	SCREW W/WASHER	1
235	429982-15	SELF-TAP SCREW	2
236	429982-16	END COVER	1
402	285802-63	COVER ASSY	1
403	285804-36	GASKET	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
404	285800-77	CAP ASSY.	1
405	285802-74	CAP ASSY.	1
406	285800-78	GASKET	2
407	285802-64	GOVERNOR	1
408	285802-66	WEIGHT	3
409	285802-65	HOLDER	1
410	285802-67	PIN	3
411	285802-68	SLIDER	1
412	285801-07	CLIP	1
413	285802-73	DOWEL PIN	2
414	285802-71	OIL SEAL	1
415	285801-12	WASHER	1
416	285802-72	BOLT	7
417	285802-70	BEARING	1
418	285802-69	BEARING	1
419	285803-03	FAN	1
420	285807-71	FLYWHEEL	1
421	285803-05	NUT	1
422	285803-06	KEY	1
423	285804-37	PULLEY	1
424	285803-08	WEIGHT	1
425	285803-07	CRANKSHAFT	1
426	285802-69	BEARING	1
427	285803-10	CAMSHAFT	1
428	285803-11	PUSH ROD	2
429	285803-12	ARM	2
430	285803-13	LIFTER	2

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
431	285800-18	PIVOT	2
432	285800-19	SPRING	1
433	285803-14	INTAKE VALVE	1
434	285803-15	VALVE	1
435	285803-16	SPRING	2
436	285803-17	RETAINER	1
437	285803-18	RETAINER	1
438	285803-19	SEAT	1
439	285803-20	ROTATOR VALVE	1
440	285803-21	PLATE	1
441	285800-27	BOLT	2
442	285800-28	NUT	2
443	285803-22	SEAL	1
444	285803-24	ARM	1
445	285803-25	ROD	1
446	285803-26	SPRING	1
447	285803-27	SPRING	1
448	285803-28	CONTROL	1
449	285800-39	SPRING	1
450	285800-41	BOLT	2
451	285800-42	BOLT	1
452	285803-29	SCREW	1
453	285800-46	NUT	1
454	285803-32	RING SET	1
454	285803-33	RING SET	1
454	285803-30	RING SET	1
454	285803-31	RING SET	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
455	285803-34	PISTON	1
456	285803-35	PIN	1
457	285806-19	CONNECTING ROD	1
458	285803-37	BOLT	2
459	285803-38	CLIP	2
460	285802-99	COVER	1
461	285803-00	SHROUD	1
462	285803-01	GROMMET	1
463	285800-41	BOLT	6
464	285803-02	CLIP	2
465	5140000-97	ENGINE	1
466	285802-76	SWITCH ASSY	1
467	285802-77	SHAFT	1
468	285802-78	GROUND WIRE	1
469	285800-41	BOLT	1
470	285804-38	BOLT	2
471	285802-79	WASHER	1
472	285802-71	OIL SEAL	1
473	285802-81	OIL SEAL	1
474	285801-10	O-RING	1
475	285801-11	NUT	1
476	285802-82	WASHER	2
477	285802-83	LOCK PIN	1
478	285801-14	BOLT	2
479	285802-70	BEARING	1
480	285801-22	OIL ALERT UNIT	1
481	285800-41	BOLT	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
482	285802-85	CYLINDER HEAD	1
483	285802-86	GUIDE	1
484	285802-87	GUIDE	1
485	285802-88	CLIP	1
486	285802-89	GASKET	1
487	285802-90	COVER	1
488	285802-91	GASKET	1
489	285802-92	BOLT	1
490	285802-93	BOLT	2
491	285802-94	BULK HOSE	1
492	285802-95	BOLT	2
493	285802-96	WASHER	1
494	285802-97	PIN	2
495	285804-79	BOLT	4
496	285800-98	SPARK PLUG	1
497	285803-39	STARTER ASSY.	1
498	285803-40	CASE	1
499	285803-41	PULLEY	1
500	285803-42	RATCHET	2
501	285803-43	SPRING	1
502	285803-44	SPRING	1
503	285803-45	SPRING	2
504	285803-46	RETAINER	1
505	285803-47	HOLDER	1
506	285803-48	GRIP	1
507	285803-49	ROPE	1
508	285803-50	SCREW	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
509	285801-53	BOLT	3
510	285803-51	TUBE	1
511	285803-52	ELELEMENT	1
512	285803-53	SEPARATOR	1
513	285803-54	HOUSING	1
514	285803-55	STAY	1
515	285803-56	COVER	1
516	285803-57	CLIP	2
517	285803-58	CLIP	2
518	285803-59	SEAL	1
519	285803-60	FILTER	1
520	285803-61	NUT	6
521	285800-46	NUT	3
522	285803-62	MUFFLER	1
523	285803-63	PROTECTOR	1
524	285803-64	PROTECTOR	1
525	285803-65	SEAL	2
526	285803-66	EXHAUST PIPE	1
527	285803-67	GASKET	1
528	285803-68	GASKET	1
529	285803-69	STAY	1
530	285803-70	ARRESTOR, SPARK	1
531	285803-71	SCREW	1
532	285803-72	NUT	4
533	285803-73	BOLT	8
534	285803-74	2552552 BOLT	2
535	285803-75	GASKET SET	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
536	285803-76	VALVE SET	1
537	285803-77	FLOAT SET	1
538	285803-78	CHAMBER SET	1
539	285800-51	SET SCREW	1
540	285803-79	SET SCREW	1
541	285803-80	SET SCREW	1
542	285803-81	CARB ASSY	1
543	285800-56	SCREW	1
544	285803-82	CAP	1
546	285803-83	NOZZLE	1
547	285803-84	COLLAR	1
548	285803-85	INSULATOR	1
549	285803-86	GASKET	1
550	285803-87	GASKET	1
551	285803-88	VALVE ASSY	1
552	285803-89	STAY ASSY	1
553	285803-90	STAY	1
554	285803-91	LEVER	1
555	285803-92	ROD JOINT	1
556	285803-93	CHOKE ROD	1
557	285803-94	STOPPER	1
558	285803-95	SPRING	1
559	285803-96	GASKET	1
560	285803-97	DIAPHRAM ASSY	1
561	285803-98	ROD	1
562	285803-99	GROMMET	1
563	285804-00	GUIDE	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
564	285804-01	CHECK VALVE	1
565	285804-02	BUSH	1
566	285804-03	GROMMET	1
567	285804-04	WASHER	1
568	285804-05	SEAL	2
569	285804-06	WASHER	1
570	285804-07	COLLAR	1
571	285804-08	CLIP	1
572	285804-09	SCREW	2
573	285804-10	SCREW & WASHER	2
574	285800-46	NUT	2
575	285804-11	WASHER	1
576	285804-12	E-RING	1
577	285804-13	E-RING	1
578	285804-14	E-RING	1
579	285804-15	TUBE CLIP	4
580	285804-16	VAC. HOSE	2
581	285804-19	MAIN JET	1
581	285804-18	MAIN JET	1
581	285804-17	MAIN JET	1
582	285800-73	JET	1
583	285804-86	IGNITION COIL	1
584	285801-30	CAPACITOR ASSY	1
585	285804-21	1724996 COIL ASSY	1
586	285804-22	COIL ASSEMBLY	1
587	285804-23	CLAMP	1
588	285804-24	GROMMET	1

Parts List for DG6000E Type 1

Item Number	Part Number	Description	Qty Required
589	285804-25	WIRE	1
590	285804-26	HOLDER	1
591	285804-27	BOLT	4
592	285800-41	BOLT	1
593	285802-29	BOLT	2
594	285804-28	EMBLEM	1
595	285804-29	CHOKE MARK	1
596	285804-30	LABEL	1
597	285804-31	LABEL	1
598	285804-32	SPRING	1
599	285804-33	LEVER	1
600	285804-34	SOLENOID	1
601	285800-41	BOLT	1
602	285804-35	SCREW	2
610	5140000-97	ENGINE	1
611	285805-74	WASHER	1
612	285807-73	STARTER ASSY.	1
846	5140019-96	TUNE-UP KIT	1
846	5140012-51	ACCESSORY KIT	1
846	5140005-21	HARDWARE BAG	1