





## Parts List for DH4240 Type 0

Item Number	Part Number	Description	Qty Required
5	5140097-94	SCREW	4
8	5140097-95	COVER	1
10	5140097-96	O-RING	1
11	5140097-97	SEAL	1
15	5140097-98	BALL BEARING	1
20	5140097-99	CONNECTING ROD	3
24	5140098-00	PLUG	1
25	5140098-26	CRANKSHAFT	1
27	5140098-02	BALL BEARING	1
32	5140097-61	OIL FILL CAP	1
33	5140097-60	O-RING	2
37	5140097-62	GAUGE	1
38	5140097-63	GASKET	1
48	5140097-64	DRAIN PLUG	1
64	5140098-01	PIN	3
65	5140098-03	ROD	3
70	5140097-67	OIL SEAL	3
75	5140098-04	SLINGER	3
90	5140098-05	PLUNGER	3
98	5140098-11	SEAL KIT	1
99	5140098-06	RETAINER	3
100	5140098-07	RETAINER	3
101	5140098-13	ADJ HANDLE	1
102	5140098-14	CAP	1
103	5140098-15	LOCK NUT	1
104	5140098-16	SET SCREW	1
108	5140098-17	SPRING	1

## Parts List for DH4240 Type 0

Item Number	Part Number	Description	Qty Required
110	5140098-18	RETAINER	1
120	5140046-25	SEAL	3
138	5140098-19	SEAT	1
139	P599	ORING CAT 13963	1
143	5140098-20	CHECK VALVE	1
144	5140098-21	SPRING	1
160	5140098-27	VALVE KIT	1
168	5140098-22	O-RING KIT	1
169	5140098-12	INJECTOR	1
170	5140098-28	REPAIR KIT	1
174	5140098-08	PLUG	3
182	5140043-78	O-RING	1
185	5140098-09	MANIFOLD	1
188	5140098-10	SCREW	8
201	5140094-91	ENGINE	1
205	5140094-92	PUMP ASSEMBLY	1
206	5140098-23	PANEL	1
208	5140095-00	HARDWARE KIT	1
209	5140098-24	FRAME ASSY.	1
210	5140098-25	HANDLE ASSY.	1
212	5140095-01	HARDWARE KIT	1
213	5140095-02	WHEEL KIT	2
218	5140094-96	HOSE CHEMICAL	1
221	5140095-03	FOOT	2
223	5140094-99	NOZZLE HOLDER RUBBER	1
224	5140095-04	NOZZLE SET	1
226	5140095-07	HOSE	1

## Parts List for DH4240 Type 0

Item Number	Part Number	Description	Qty Required
227	5140095-05	GUN	1
228	5140094-94	COUPLER	1
239	5140095-85	VALVE THERMAL RELIEF	1
240	5140095-06	LANCE	1
242	5140097-93	INLET ADAPTER	1