



862

Parts List for DR340B Type 1

Item Number	Part Number	Description	Qty Required
1	90510031	KEYLESS CHUCK	1
2	157312-02	CHUCK SCREW	1
4	90560638	SPRING	1
6	90558542	BAR	1
7	633510-00	BAR,PIVOT	1
8	90560612	SWITCH	1
9	770235	CORD PROTECTOR	1
12	330019-63	SCREW	1
13	90559941	NAME PLATE	1
14	148354-03	BIT CLIP	1
15	90511915	CORDSET	1
16	330019-03	SCREW	9
17	90539116	WARNING LABEL	1
18	607918-55	SCREWDRIVER BIT	1
19	635697-01	BRUSH RING ASY	1
20	90552990	BRUSH	2
862	90533670	TOOL BAG	1