



Parts List for DW008K Type 1

Item Number	Part Number	Description	Qty Required
1	388870-00	HANDLE & COVER	1
2	152274-16	SWITCH	1
3	390008-00	LEVER	1
4	388869-00	FIELD CASE	1
5	330003-60	BEARING	2
6	390759-00	BEARING	1
7	382178-01	BRUSH RING	1
8	390772-01	BRUSH	2
9	445860-00	SPRING,BRUSH	2
10	388232-01SV	MAGNET RING	1
11	387671-00SV	ARMATURE	1
12	388866-00	FAN BAFFLE	1
13	448269-00	SCREW	2
14	000000-00	No Longer Available	1
15	388990-00	GEAR CASE ASY	1
16	000000-00	No Longer Available	1
17	330045-05	LOCK SCREW	8
18	389998-00	NUT (R.H.)	1
19	382187-00	PIN,WRIST	1
20	394564-01	OUT.SHAFT & PIN	1
21	388992-00	RELEASE BUTTON	1
22	388993-00	RELEASE SPRING	1
23	388873-00	BOOT	1
24	383435-02	SHOE ASSEMBLY	1
25	390229-00	BLD STORAGE PLG	1
26	389054-00	THUMB PLUG	2
27	387530-00	TERMINAL BLOCK	1

Parts List for DW008K Type 1

Item Number	Part Number	Description	Qty Required
28	930026-01	BUMPER	1
29	388988-00	GASKET	1
30	384405-00	BUTTON	1
31	330019-04	SCREW,PLASTITE	7
32	390017-00	LEADWIRE	1
33	390016-00	LEADWIRE	1
34	330045-06	SCREW	2
35	383745-00	PLATE,RETAINING	1
36	383227-00	CAP	1
38	383197-01	WOBBLE DRIVER	1
39	385872-02	WOBBLE ASSY	1
40	383201-00	HUB,WOBBLE	1
41	058836-00	RING	1
42	383668-01	BRG RETAINER	1
43	389999-00	SPACER PLATE	1
44	390019-00	LABEL,IDENT.	1
45	389989-01	NAMEPLATE	1
46	330003-12	BEARING,BALL	2
47	384046-00	RETAINING RING	1
48	620663-00	CLAMP PIN	1
49	383749-01	SLIDER	1
50	604731-00	BL CLAMP COLLAR	1
51	623343-00	SPRING	1
52	387425-00	STEEL BALL	3
53	391452-00	LEVER,SA	1
54	613056-00	PIN	1
55	045550-00	SPRING	1

Parts List for DW008K Type 1

Item Number	Part Number	Description	Qty Required
56	330019-15	SCREW	4
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
800	286436-00	GREASE	1
856	DW4878	6IN 18TPI CDLS STGHT BLDE	1
856	DW4876	6TPI CORDLESS TAPER BLADE	1
861	390407-00	KIT BOX	1
866	DW0242	BATTERY, 24V	1
867	608262-00	BATTERY CAP	1
871	DW0246	24V CHARGER	1