



## Parts List for DW616M Type 1

Item Number	Part Number	Description	Qty Required
1	396310-01	MOTOR HOUSING	1
2	146555-01	BEARING, BALL	1
3	394219-00	CLAMP NUT	1
4	398221-00SV	ARMATURE & BRG.	1
5	330045-57	SCREW	3
6	399064-00	TOGGLE SWITCH	1
7	399028-00	SWITCH BOOT	1
8	397500-00	RECEPTACLE	1
9	397501-00	WIRE GUARD	1
10	397564-00	END CAP	1
11	33055-00	PLUG	1
12	330045-09	SCREW	4
13	150036-00	SCREW,GROUND	1
14	399063-00	CORDSET	1
15	330003-09	BEARING,BALL	1
16	053650-03	TERMINAL	1
17	608552-00	GROUND WIRE	1
18	608551-00	LEADWIRE	1
19	397566-01	BRUSH RING ASM	1
20	398139-01	BRUSH ASSY.	2
21	397569-00SV	FIELD	1
22	330019-27	SCREW,TORX	2
23	398216-00	FIELD CASE	1
24	5140060-14	COLLET & NUT	1
24	326286-04	COLLET & NUT	1
24	326286-03	COLLET & NUT	1
25	399068-00	WRENCH	2

## Parts List for DW616M Type 1

Item Number	Part Number	Description	Qty Required
26	612616-00	NAME PLATE	1