



Parts List for DW678K-BR Type 2

Item Number	Part Number	Description	Qty Required
1	578603-02	ARMATURE	1
2	327429-10	FIELD	1
3	327383-01	SWITCH,TRIGGER	1
4	575963-00	BRUSH	2
5	582573-00	CORDSET	1
6	574232-01	BLADE DRUM ASSY	1
7	770235	CORD PROTECTOR	1
8	329301-00	CLAMP,CORD	1
9	330065-06	SCREW	2
10	323768-14	LEAD ASSY.	1
12	323768-15	LEAD ASSY.	1
13	326592-00	CAP	1
14	328772-00	NUT	1
15	326590-01	BASE	1
16	326589-02	SCALE	1
17	326381-00	RATCHET	1
18	327341-00	WASHER,SPRING	1
20	326629-00	COVER,BRUSH	1
21	326636-00	POST	2
22	330065-08	SCREW	16
25	323722-00	SPRING	1
26	326823-01	BUSHING	1
27	324006-00	SCREW	1
28	327387-00	DEFLECTOR,CHIP	1
29	324006-11	SCREW	1
30	578758-00	IDENT. LABEL	1
32	572255-00	SPRING	1

Parts List for DW678K-BR Type 2

Item Number	Part Number	Description	Qty Required
34	323481-00	CAP	1
35	605040-63	BEARING	1
37	326596-00	BAFFLE	1
39	324006-06	SCREW	3
40	000000-00	No Longer Available	1
41	605040-23	BALL BEARING	1
42	577745-00	BALL BEARING	1
43	324105-00	PULLEY,SMALL	1
44	327065-00	PINION	1
45	325106-00	BELT,TOOTHED	1
46	761225-02	NUT	1
47	329269-00	COVER,BELT	1
48	000000-00	No Longer Available	1
54	330004-31	BEARING	1
55	327392-00	ADAPTOR,VAC	1
57	327393-00	GUIDE	1
58	326573-01	SCREW,WING	2
59	327391-00	FENCE	1
60	328834-00	NUT,WING	1
61	911111-00	BOLT	1
62	328175-00	BRACKET	1
64	326637-00	GUARD	1
68	330065-10	SCREW	2
70	577706-00	CLAMP ASSEMBLY	2
72	326635-01	STAND	1
82	868148-00	SPANNER	1
91	941486-00	CABLE TIE	1

Parts List for DW678K-BR Type 2

Item Number	Part Number	Description	Qty Required
97	329145-00	CLIP	1
101	327390-00	ADAPTOR	1
102	248630-00	HOLDER	1
103	80271901	FRAME	1
104	329452-00	DUST BAG	1
105	249233-00	WASHER	1
107	329829-00	SEAL	1
109	329780-49	BRUSH HOLDER	1
110	000000-00	No Longer Available	1