



Parts List for DW679 Type 1

Item Number	Part Number	Description	Qty Required
101	868630-01	ARMATURE,120V	1
102	868629-03	FIELD,120V	1
103	760952-00	SWITCH	1
104	930802-00	BRUSH	2
105	949738-08	POWER CORD	1
106	949835-01	PROTECTOR,CORD	1
107	935616-00	CLAMP,CORD	1
108	000000-00	No Longer Available	2
109	930029-00	COVER,BRG	1
110	330003-34	BEARING,BALL	1
111	930079-01	SCREW	6
112	944137-00	RING	1
113	868768-02	BEARING	1
114	931398-00	RING,SEEGER	1
115	944484-00	RING,LOCKING	1
116	930749-00	HOLDER,BR.	1
117	930090-00	SPRING	2
118	930077-00	SCREW	2
119	943173-00	BAFFLE	1
120	933657-00	CAP	2
122	943172-02	HANDLE ASSY.	1
123	943169-02	CASE,FIELD	1
124	949801-13	LEAD	1
125	949801-13	LEAD	1
126	943178-01	HOUSING	1
127	943051-00	SPRING	1
128	944386-00	COVER	1

Parts List for DW679 Type 1

Item Number	Part Number	Description	Qty Required
129	947048-00	BUTTON	1
130	930224-00	SCREW,M4X10	2
145	868629-01	FIELD ASSY	1
153	945393-00	WRENCH	1
154	943270-00	NUT,COLLET	1
155	943269-01	COLLET,6.35MM	1
160	946194-00	LABEL	1
161	947965-00	NAMEPLATE	1