



Parts List for DW831-AR Type 4

Item Number	Part Number	Description	Qty Required
101	397337-02	ARMATURE KIT	1
102	654390-03	FIELD,230V	1
103	N015909	SWITCH	1
104	654631-07	BRUSH	2
105	N158291	CORD & PLUG	1
106	401678-05	FLANGE	1
107	391969-00	CLAMP WASHER	1
108	562160-06	SCREW	3
109	N043269	PLATE	1
110	N042945	GUARD	1
111	393576-00	GUARD SPRING	1
112	330045-46	SCREW	4
113	390521-01	COVER,GEARCASE	1
114	652000-00	SPINDLE	1
115	402849-00	BRUSH COVER	2
116	330005-01	PROTECTOR,CORD	1
117	390522-00	GEAR	1
118	562097-10	SCREW	4
119	569905-04	GEAR CASE	1
121	N239381	SIDE HANDLE	1
122	398976-00	FLANGE	1
123	393568-00	NUT	1
124	390705-00	BUTTON,LOCK	1
125	562210-00	SPRING	1
126	390704-00	LOCK,SPINDLE	1
127	605040-22	BEARING	1
128	641823-00	BEARING CUP	1

Parts List for DW831-AR Type 4

Item Number	Part Number	Description	Qty Required
129	656706-00	BAFFLE	1
130	605040-60	BEARING	1
131	930753-00	WASHER	1
132	402869-11	BRUSH HOLDER ASSY	2
133	387746-00	SCREW	4
134	402871-25	FIELD CASE	1
135	605040-03	BALL BEARING	1
136	402844-11	HANDLE ASSY.	1
137	930103-00	CLAMP, CORD	1
138	401680-00	WRENCH	1
139	562097-00	SCREW	5
140	399032-01	FLANGE	1
143	562097-11	SCREW	2
144	562097-03	SCREW	4
145	945280-00	SCREW	2
149	403123-00	RING, O	1
151	398941-00	IDENT. LABEL	1
152	402847-00	DAMPER	4
153	402863-00	PINION	1
155	650937-00	INSULATING PAPER	1
166	398985-00	SLINGER	1
167	398909-00SV	GREASE RETAINER	1
168	399052-00	FELT WASHER	1
169	403148-00	WASHER	1
170	50050-00	RING	1
171	N158292	NAME PLATE	1
173	620051-00	PAD	2

Parts List for DW831-AR Type 4

Item Number	Part Number	Description	Qty Required
174	641893-00	FELT SEAL	1
800	286436-00	GREASE, 500GRAMS	1