



## Parts List for DW887-B2 Type 4

Item Number	Part Number	Description	Qty Required
1	618806-00SV	ARMATURE	1
2	619023-00SV	FIELD	1
3	445861-30	BRUSH & LEAD	2
4	445860-00	SPRING,BRUSH	2
5	449899-05	RING,BRUSH	1
6	N107382	END CAP	1
7	625238-00	SWITCH	1
7	625238-00	SWITCH	1
7	625238-00	SWITCH	1
8	330122-05	CORD,PWR SUPPLY	1
9	330003-04	BEARING,BALL	1
10	330003-08	BEARING,BALL	1
11	330005-01	PROTECTOR,CORD	1
12	444793-00	RING, RETAINING	1
13	448269-00	SCREW	2
14	464228-00	TERMINAL	2
16	445857-03	CASE,FIELD	1
17	330019-13	SCREW,M4X19	8
18	397655-00SV	PADDLE ASSY.	1
19	445217-01	RUBBER CUP	1
22	N115041	LEAD ASSY.	2
23	397659-00	LOCK BUTTON	1
25	384432-00SV	HOUSING	1
26	445876-00	BAFFLE, FAN	1
28	450826-00	COUPLING	2
29	464205-00	DRIVER,KEY	1
30	034808-00	CLOSURE	1

## Parts List for DW887-B2 Type 4

Item Number	Part Number	Description	Qty Required
31	021955-00	SLEEVE	1
33	330003-08	BEARING,BALL	1
34	400834-00	WASHER	2
36	448373-00	WASHER,SPRING	1
38	380725-00	SLEEVE	1
40	385244-00	RING,RETAINING	1
41	N115813	SPINDLE	1
42	045488-00	COLLET	1
46	N126311	NAME PLATE	1
47	397611-00	SPRING,COMP.	1
48	380722-00	COVER	1
49	330003-08	BEARING,BALL	1
50	395047-00	ID LABEL	1
60	030076-00	WRENCH	2
846	N110834	PLUG	1