



Parts List for DW888-B2 Type 3

Item Number	Part Number	Description	Qty Required
1	450964-01SV	ARMATURE & BRGS	1
2	450832-72SV	FIELD	1
3	450374-12	BRUSH & SPRING	2
4	448083-01	HOLDER,BRUSH	2
5	448084-01	CAP,BRUSH	2
6	395373-01	SWITCH	1
7	330122-09	CORD & PLUG	1
8	330003-04	BEARING,BALL	1
9	330003-09	BEARING,BALL	1
10	330044-23	SCREW	2
11	330019-15	SCREW	4
12	330019-13	SCREW,M4X19	7
13	330019-01	SCREW,TORX HD	1
14	330019-03	SCREW	2
15	N084757	COLLET	1
15	158442-00	1/4 COLLET	1
16	146569-01	NUT	1
17	150844-01	PAD	2
18	021955-00	SLEEVE	1
19	450828-00	HOUSING,WHEEL	1
20	448079-00	PLATE,BEARING	1
21	447786-00	BAFFLE,FAN	1
22	445217-02	SLEEVE	1
23	448170-11	HANDLE & COVER	1
24	330005-01	PROTECTOR,CORD	1
25	450877-00	CORD CLAMP	1
26	448172-00	TERMINAL	1

Parts List for DW888-B2 Type 3

Item Number	Part Number	Description	Qty Required
27	5140112-75	COUPLING ASSY	1
27	450826-00	COUPLING	2
29	99180-24	O-RING	1
33	450823-00	SHAFT	1
34	144482-00	BEARING,BALL	1
35	330003-09	BEARING,BALL	1
36	450825-00	BRG.RETAINER	1
38	146637-00	SLEEVE	1
39	144803-00	RING,RET.	1
40	651176-00	NAMEPLATE	1
43	447799-08	CASE,FIELD	1
44	053650-00	TERMINAL	3
46	5140112-75	COUPLING ASSY	1
46	464205-00	DRIVER,KEY	1
47	150844-03	PAD	4
48	384127-01	SCREW	4
49	627212-00	ID LABEL	1
50	395716-00	TERMINAL	2
60	020285-00	WRENCH	2
61	703131-00	WRENCH	1