



DATE CODE

## Parts List for DWE357 Type 2

Item Number	Part Number	Description	Qty Required
1	N377247	FIELD CASE	1
2	N408140	FIELD	1
3	N408690	BRUSH RING ASM	1
4	330019-18	SCREW,PLASTITE	2
5	330019-32	SCREW	2
6	N115654	FAN BAFFLE	1
7	N408097	ARMATURE & BRGS	1
8	694432	BEARING MOUNT	1
9	N143636	FELT SEAL	1
10	N195818	GEAR CASE ASM	1
11	N129171	ORING	1
12	N130874	SCREW #8X1.00 PAN HD	4
13	N143177	SPACER RING	1
14	N124072	THRUST RING	1
15	N115646	THRUST BEARING	1
16	N115647	THRUST RING	1
17	N195823	GEAR ASSEMBLY	1
18	N115642	PLATE, THRUST	1
19	142940-00	SCREW	5
20	N195829	GEAR CASE COVER ASSY	1
21	621979-00	WEAR STRIP	2
22	618733-00	SHAFT SEAL	1
23	618477-00	FELT SEAL	1
24	N020720	SEAL PLATE	1
25	330045-43	SCREW,TAPTITE	1
26	N413035	RECIP. SHAFT ASSY.	1
27	000903-00	BALL	1

## Parts List for DWE357 Type 2

Item Number	Part Number	Description	Qty Required
28	622647-00	SLIDER	1
29	622659-00	TORSION SPRING	1
30	658115-00	YOKE CHANNEL	1
31	617000-00	SADDLE	1
32	N191614	FLAT HD SCREW	2
33	N191590	LOCK NUT	2
34	N021857	BEARING	1
35	N385787	GASKET,GEARCASE	1
36	N115637	CAP,END	1
37	N131037	CAP	2
38	144457-02	SCREW	4
39	N115631	LEVER ASSEMBLY	1
40	N115626	BOOT	1
41	N388222	HOUSING ASSEMBLY	1
43	N054825SV	SWITCH	1
44	330019-01	SCREW,TORX HD	1
45	N366219	CORD,PWR SUPPLY	1
46	330005-01	PROTECTOR,CORD	1
47	N226256	SHOE ASSEMBLY	1
48	N377528	LABEL	1
50	330019-13	SCREW,PLASTITE	9
51	855284	BEARING	1
52	330003-09	BEARING,BALL	1
53	N166858	FELT WASHER	1
54	N172838	SUPPORT COLLAR	1
100	384719-01	BRUSH	2
101	383387-00	SPRING,BRUSH	2

## Parts List for DWE357 Type 2

Item Number	Part Number	Description	Qty Required
800	429698-00	GREASE:4 LB CAN	1
862	N184944	TOOL BAG	1