





Parts List for DXCMH1393075 Type 0

Item Number	Part Number	Description	Qty Required
1	5140177-28	HUB	1
2	5140177-29	PULLEY	1
3	5140177-30	V-BELT	2
4	5140177-31	BELT GUARD	1
5	5140153-35	SCREW	8
6	5140153-33	WASHER	8
7	5140153-39	U-NUT	4
8	5140177-32	BRACKET	2
9	5140176-27	KEY	1
11	5140177-33	BELT GUARD	1
12	5140153-29	SCREW	3
13	5140153-32	WASHER	15
14	5140177-34	STABILIZER BAR	1
15	5140177-35	BOLTING PLATE	2
16	5140197-72	SCREW	2
18	5140176-84	PUMP ASSEMBLY	1
19	5140176-23	SCREW	8
20	5140153-26	NUT	8
21	5140119-08	O-RING	1
21	5140177-38	BUSHING	1
21	5140172-91	DRAIN VALVE	1
21	5140119-07	BUSHING	1
22	5140177-39	VIBRATION PAD	4
23	5140156-26	NIPPLE	1
24	5140119-91	PRESSURE RELIEF VALV	1
25	5140120-57	TEE 1/4	1
26	5140172-88	PRESSURE GAUGE	1

Parts List for DXCMH1393075 Type 0

Item Number	Part Number	Description	Qty Required
27	5140177-40	BLEEDER TUBE	1
28	5140119-17	NUT	2
29	5140177-41	UNLOADER	1
30	5140121-06	CONNECTOR	1
31	5140119-17	NUT	2
32	5140177-42	BLEEDER TUBE	1
33	5140119-64	ELBOW	1
34	5140177-43	THROTTLE CONTROL	1
36	5140177-44	CONNECTOR	1
37	5140119-65	CHECK VALVE	1
38	5140119-63	CONNECTOR	1
39	5140121-84	COMPRESSION NUT	1
40	5140177-45	TRANSFER TUBE	1
41	5140177-46	ELBOW	1
42	5140119-07	BUSHING	1
43	5140173-00	CAUTION LABEL	1
44	5140177-47	WARNING LABEL	1
45	5140172-89	WARNING LABEL	1
46	5140119-14	WARNING LABEL	2
50	5140177-52	WARNING LABEL	1
103	5140176-48	HEAD BOLT	9
104	5140153-51	LOCK WASHER	22
105	5140176-49	CYLINDER HEAD	1
106	5140176-50	GASKET	1
109	5140176-51	GASKET	1
113	5140176-52	GASKET	1
116	5140176-55	PISTON	1

Parts List for DXCMH1393075 Type 0

Item Number	Part Number	Description	Qty Required
117	5140176-56	WRIST PIN	1
118	5140176-57	PISTON	1
119	5140176-58	WRIST PIN	1
120	5140176-59	RETAINING RING	4
121	5140176-60	CYLINDER	1
122	5140176-61	GASKET	1
123	5140176-62	NUT	6
124	5140176-63	BOLT	6
125	5140176-64	CONNECTING ROD ASSY.	2
127	5140176-65	BEARING	1
128	5140176-66	NEEDLE BEARING	2
132	5140153-68	BREATHER CAP	1
133	5140153-69	CONNECTOR	1
134	5140176-67	BREATHER TUBE	1
135	5140153-71	BOLT	1
136	5140153-72	REAR BEARING CARRIER	1
137	5140153-73	GASKET	1
138	5140153-74	FILTER	1
139	5140153-75	SIGHT GLASS	1
140	5140153-76	PLUG	1
141	5140176-68	CRANKCASE	1
142	5140153-78	BEARING	2
143	5140176-69	CRANKSHAFT	1
144	5140153-80	KEY	1
145	5140176-70	OIL SEAL	1
146	5140176-71	FLYWHEEL	1
147	5140153-83	WASHER	1

Parts List for DXCMH1393075 Type 0

Item Number	Part Number	Description	Qty Required
148	5140153-84	WASHER	1
149	5140153-85	BOLT	1
150	5140176-24	TRANSFER TUBE	1
151	5140153-87	PRESSURE RELIEF VALV	1
152	5140176-73	ELBOW	1
154	5140176-75	VALVE PLATE ASSEMBLY	1
155	5140176-76	RING SET	1
156	5140176-77	RING SET	1
157	5140176-78	PIPE CAP	1
158	5140176-79	NIPPLE	1
159	5140156-33	NUT	1
160	5140176-80	WASHER	1
161	5140176-81	BOLT	1
162	5140177-53	NIPPLE	1
163	5140176-74	ELBOW	1
163	5140177-54	ELBOW	1
164	5140176-46	FILTER ASSEMBLY	1
164	5140177-55	FILTER CANN. ASSY	1
165	5140176-82	GASKET SET	1
166	5140176-83	OVERHAUL KIT	1
167	5140176-47	FILTER ELEMENT	1
167	5140177-56	FILTER	1