





Parts List for DXCMH9919910 Type 0

Item Number	Part Number	Description	Qty Required
1	5140153-35	SCREW	6
2	5140153-33	WASHER	10
3	5140153-39	U-NUT	1
4	5140183-44	BELT GUARD	1
6	5140176-39	HUB	1
7	5140176-39	HUB	1
8	5140183-46	PULLEY	1
9	5140153-25	V-BELT	1
10	5140183-47	BELT GUARD	1
11	5140153-36	SCREW	2
12	5140153-28	LOCK NUT	2
13	5140183-48	REDUCER	1
14	5140153-40	BRACKET	2
15	5140153-29	SCREW	6
16	5140153-32	WASHER	12
17	5140121-87	PRESSURE SWITCH	1
18	5140119-55	GAUGE	1
19	5140119-60	VALVE, BLEEDER	1
20	5140156-26	NIPPLE	1
21	5140119-91	PRESSURE RELIEF VALV	1
22	5140119-58	STRAIN RELIEF	1
23	5140119-57	SCREW	1
24	5140183-49	MOTOR	1
25	5140183-50	CORD	1
26	5140176-36	CORD	1
27	5140176-25	SCREW	4
28	5140153-26	NUT	4

Parts List for DXCMH9919910 Type 0

Item Number	Part Number	Description	Qty Required
29	5140119-81	WARNING LABEL	1
30	5140119-13	WARNING LABEL	1
31	5140119-72	O-RING	2
31	5140119-74	BUSHING	1
31	5140119-71	BUSHING	1
31	5140172-91	DRAIN VALVE	1
32	5140119-74	BUSHING	1
33	5140176-44	PLUG	1
34	5140177-46	ELBOW	1
35	5140119-14	WARNING LABEL	1
36	5140183-51	BRACKET	2
37	5140204-45	MAGNETIC STARTER	1
38	5140156-22	BOLT	2
39	5140176-37	STRAIN RELIEF	1
40	5140119-90	STRAIN RELIEF	1
41	5140183-53	WASHER	4
42	000000-00	No Longer Available	4
43	000000-00	No Longer Available	4
44	5140183-86	PUMP ASSEMBLY	1
45	5140204-46	CHECK VALVE	1
46	5140121-06	CONNECTOR	1
47	5140183-56	TRANSFER TUBE	1
48	5140204-47	COMPRESSION NUT	1
49	5140177-98	SCREW	2
50	5140183-57	BLEEDER TUBE	1
51	5140183-58	ELBOW	1
52	5140183-59	OUTLET TUBE	1

Parts List for DXCMH9919910 Type 0

Item Number	Part Number	Description	Qty Required
53	5140177-39	VIBRATION PAD	4
54	5140153-27	NUT	1
55	5140176-42	WASHER	5
56	5140176-45	WASHER	1
101	5140153-48	FILTER ASSEMBLY	2
102	5140153-49	FILTER ELEMENT	2
103	5140153-50	HEAD BOLT	18
104	5140153-51	LOCK WASHER	36
105	5140183-60	CYLINDER HEAD	2
106	5140153-53	GASKET	2
109	5140153-54	GASKET	2
113	5140153-55	GASKET	2
114	5140183-61	OUTLET TUBE	2
115	5140183-59	OUTLET TUBE	1
116	5140153-56	PISTON	2
117	5140153-57	WRIST PIN	2
118	5140153-58	PISTON	2
119	5140153-59	WRIST PIN	2
120	5140153-60	RETAINING RING	8
121	5140153-61	CYLINDER HEAD	2
122	5140153-62	GASKET	2
123	5140153-63	NUT	12
124	5140153-64	BOLT	12
125	5140153-65	CONNECTING ROD ASSY.	4
127	5140153-66	BEARING	4
128	5140153-67	NEEDLE BEARING	4
132	5140153-68	BREATHER CAP	1

Parts List for DXCMH9919910 Type 0

Item Number	Part Number	Description	Qty Required
133	5140153-69	CONNECTOR	1
134	5140183-62	BREATHER TUBE	1
135	5140153-71	BOLT	6
136	5140183-63	BEARING CARRIER	1
137	5140153-73	GASKET	1
138	5140183-64	FILTER	1
139	5140183-65	SIGHT GLASS	1
140	5140183-66	NIPPLE	1
141	5140183-67	CRANKCASE	1
142	5140183-68	BEARING	1
143	5140183-69	CRANKSHAFT	1
144	5140183-70	KEY	1
145	5140183-71	OIL SEAL	1
146	5140183-72	FLYWHEEL	1
147	5140183-73	WASHER	1
148	5140183-74	WASHER	1
149	5140183-75	BOLT	1
150	5140183-76	PLUG	1
151	5140153-87	PRESSURE RELIEF VALV	1
152	5140153-88	ELBOW	2
153	5140153-89	ELBOW	3
154	5140183-58	ELBOW	1
155	5140183-77	BEARING	1
156	5140183-78	SPRING WASHER	1
157	5140183-79	FAN BLADE	1
158	5140183-80	SPRING WASHER	6
159	5140183-81	WASHER	6

Parts List for DXCMH9919910 Type 0

Item Number	Part Number	Description	Qty Required
160	5140183-82	BOLT	6
161	5140183-83	PIPE CAP	1
162	5140153-90	VALVE PLATE ASSEMBLY	2
163	5140153-91	RING SET	2
164	5140153-92	RING SET	2
165	5140183-84	GASKET SET	1
166	5140183-85	OVERHAUL KIT	1