





Parts List for DXPW3425 Type 0

Item Number	Part Number	Description	Qty Required
1	5140142-64	BASE FRAME	1
2	5140142-65	REAR HANDLE ASSY.	1
4	5140110-09	WOODRUFF KEY	1
5	5140181-32	PUMP ASSEMBLY	1
5	5140142-66	PUMP ASSEMBLY	1
6	5140112-51	WHEEL ASSY.	2
7	5140095-03	FOOT	2
8	5140095-89	HARDWARE KIT	1
9	5140095-90	HARDWARE KIT	1
10	5140112-52	HARDWARE KIT	2
11	5140109-33	HANDLE GRIP	1
12	5140112-67	NOZZLE SET	1
13	5140174-69	GUN	1
14	5140095-94	LANCE	1
15	5140142-72	HOSE	1
16	5140094-96	HOSE CHEMICAL	1
201	5140117-54	WATER INLET SCREEN	1
202	5140117-12	WATER INLET CONN.	1
203	5140117-13	NUT	1
204	5140117-56	SCREW	3
205	5140114-78	SCREW	3
206	5140142-67	SET SCREW	1
207	5140095-85	VALVE THERMAL RELIEF	1
208	5140117-15	MANIFOLD	1
213	5140117-16	O-RING	1
219	5140117-17	VALVE SEAT	1
220	5140117-18	O-RING	1

Parts List for DXPW3425 Type 0

Item Number	Part Number	Description	Qty Required
221	5140117-19	UNLOADER VALVE BALL	1
222	5140117-20	SOAP INJECTOR BODY	1
223	5140117-21	BOOST VALVE CAP	1
224	5140117-22	BOOST VALVE SPRING	1
225	5140117-23	PRESSURE BOOST VALVE	1
226	5140117-24	O-RING	1
227	5140117-25	O-RING	1
236	5140117-26	MANIFOLD PLUG	3
237	5140117-27	O-RING	5
245	5140117-28	RETAINER	3
248	5140117-29	RETAINER SEAL	3
250	5140117-30	CRANKCASE PLUG	2
251	5140117-31	OIL SEAL	1
252	5140117-32	RETAINING RING	1
253	5140117-33	CRANKSHAFT BEARING	1
254	5140098-16	SET SCREW	1
256	5140117-34	CRANKSHAFT BEARING	1
257	5140117-35	RETAINING RING	1
264	5140133-37	GASKET	1
265	5140117-37	CONNECTING ROD	3
266	5140117-38	PIN	3
267	5140117-39	PISTON	3
268	5140153-07	CRANKCASE KIT	1
268	5140117-40	CRANKCASE	1
270	5140136-21	CRANKCASE END COVER	1
271	5140117-46	VALVE KIT	6
272	5140117-47	SOAP INJECTOR KIT	1

Parts List for DXPW3425 Type 0

Item Number	Part Number	Description	Qty Required
273	5140117-48	UNLOADER KIT	1
274	5140117-49	UNLOADER CHK/VLV KIT	1
275	5140117-50	OIL SEAL KIT	1
276	5140117-51	PRESSURE SEAL KIT	1
277	5140142-70	CRANKCASE COVER KIT	1
280	5140142-71	OUTLET FITTING KIT	1
301	5140117-54	WATER INLET SCREEN	1
302	5140117-12	WATER INLET CONN.	1
303	5140117-13	NUT	1
304	5140117-56	SCREW	3
305	5140114-78	SCREW	3
306	5140142-67	SET SCREW	1
307	5140095-85	VALVE THERMAL RELIEF	1
308	5140117-15	MANIFOLD	1
319	5140117-17	VALVE SEAT	1
320	5140117-18	O-RING	1
321	5140117-19	UNLOADER VALVE BALL	1
322	5140117-20	SOAP INJECTOR BODY	1
323	5140117-21	BOOST VALVE CAP	1
324	5140117-22	BOOST VALVE SPRING	1
325	5140142-71	OUTLET FITTING KIT	1
326	5140117-24	O-RING	1
327	5140117-25	O-RING	1
336	5140117-26	MANIFOLD PLUG	3
337	5140117-27	O-RING	5
345	5140117-28	RETAINER	3
348	5140117-29	RETAINER SEAL	3

Parts List for DXPW3425 Type 0

Item Number	Part Number	Description	Qty Required
350	5140117-30	CRANKCASE PLUG	2
351	5140117-31	OIL SEAL	1
352	5140117-32	RETAINING RING	1
353	5140117-33	CRANKSHAFT BEARING	1
354	5140098-16	SET SCREW	1
356	5140117-34	CRANKSHAFT BEARING	1
357	5140117-35	RETAINING RING	1
363	5140095-11	SCREW	7
364	5140133-37	GASKET	1
365	5140117-37	CONNECTING ROD	3
366	5140117-38	PIN	3
367	5140117-39	PISTON	3
368	5140117-40	CRANKCASE	1
370	5140136-21	CRANKCASE END COVER	1
371	5140117-46	VALVE KIT	6
372	5140117-47	SOAP INJECTOR KIT	1
373	5140181-33	UNLOADER KIT	1
374	5140117-49	UNLOADER CHK/VLV KIT	1
375	5140117-50	OIL SEAL KIT	1
376	5140117-51	PRESSURE SEAL KIT	1
377	5140142-70	CRANKCASE COVER KIT	1
378	5140181-34	MANIFOLD KIT	1
380	5140142-71	OUTLET FITTING KIT	1
856	5140110-40	NOZZLE CLEANING TOOL	1
876	5140118-54	MANIFOLD KIT	1