



## EC 10SC

Item No.	Code No.	Part Name	Q'ty
1	881-484	Screw	3
2	882-625	Cover Convevor	1
3	882-588	Plates and Valves Set	1
4	881-457	Set of Gasket	1
5	881-458	Valve Plate	2
6	881-459	Cylinder	1
7	882-589	Conrod and Piston Set	1
8	881-461	Piston	1
9	881-462	Piston Pin	1
10	881-463	Ring	2
11	881-561	Connecting Rod	1
12	881-465	Stud Bolt	2
13	881-455	Joint	1
14	881-454	Screw	1
15	882-621	Head	1
16	881-453	Filter Plate	1
17	882-620	Intake Filter	1
18	881-450	Screw	1
19	881-490	Set of Valve	1
20	881-489	Nut	2
21	881-460	Piston Ring	1
22	-	Nameplate	1
23	882-624	Housing	1
24	881-469	Dipstick	1
25	881-468	Seeger	1
26	881-407	Capacitor	1
27	882-626	Capacitor	1
28	881-485	Washer	1
29	881-484	Screw	1
30	881-471	Screw	1
31	881-472	Screw	3
32	882-622	Carter Cover	1
33	881-473	Gasket	1
34	882-580	Crank Shaft	1
35	881-466	Ball Bearing	1
36	881-474	Smim Ring	1
37	882-581	Carter	1
38	882-623	Rotor	1
39	882-590	Carter Shaft and Rotor Set	1
40	882-583	Motor	1
41	881-478	Ball Bearing	1
42	882-585	Cover	1
43	881-480	Tension Rod	1
44	881-483	Fan	1
45	881-503	Infeed Cable	1
46	-	Warning Label (A)	1

Item No.	Code No.	Part Name	Q'ty
47	881-509	Joint	1
48	881-510	Pressure Reducer	1
49	881-511	Joint	1
50	881-493	Safety Valve	1
51	882-591	Pressure Gauge	2
52	881-575	Pressure Switch	1
53	881-576	Joint	1
54	-	Warning Label (C)	1
55	882-584	Base	1
56	881-410	Screw	4
57	881-505	Joint	1
58	881-504	Blocking Nut	1
59	882-633	Plug	1
60	-	Warning Label (E)	1
61	882-627	Infeed Tube	1
62	882-628	Non Return Valve	1
63	881-496	Tube	1
64	882-629	Nut	4
65	881-498	Discharge Tap	1
66	882-631	Wheel	2
67	882-630	Screw	2
68	-	Warning Label (D)	1
69	882-632	Rubber	1
70	-	HITACHI Label	1

Parts are subject to change without any obligation on the part of the HITACHI due to improvements.