



EH2500 Generator UT-03644 - Engine & Frame



Rendered by LeadVenture, Inc.


<b>Ref #</b>	<b>Part #</b>	<b>Description</b>	<b>Qty</b>	<b>Context Note</b>
1		ENGINE (EH2500)	1	
2	49613	DECAL- Warning	1	
3	498081	MEMBER- Frame (engine)	1	
4	81162	NUT- Hex (5/16-18)	7	
5	83081	WASHER- Lock int. (5/16")	1	
6	83033	WASHER- Lock ext./int.	16	
7	JA400200	BOLT- Engine (rear)	2	
8	84032	WASHER- Flat (5/16")	4	
9	49733	SPACER- Foot	4	
10	48789	FOOT	4	
11	JA400204	SCREW- Cap hex. hd. (5/16-18 x 3")	2	
12	84058	WASHER- Flat (5/16")	4	
13	49490	DECAL- Ground	1	
14	498091	FRAME- Member (generator)	1	
15	498421	PLATE- Frame	1	
16	82530	BOLT- Engine (front)	2	

EH2500 Generator UT-03644 - Generator



Ref #	Part #	Description	Qty	Context Note
1	0120907	END COVER	1	
2	49495	DECAL- Warning	1	
3	50991	RECEPTACLE (120V) (EH2500)	1	
	49832	RECEPTACLE (120V) (EH2500 CSA)	1	
4	81009	NUT (120V receptacle)	2	
5	0120911	SCREW- (m5 x 12mm) (brush holder)	3	
6	A47610	LEAD- Electrical (ground)	1	
7	0120913	BOLT- Stator	4	
8	83033	WASHER- Lock ext./int.	2	
9	0120905	END BELL	1	
10	0120910	GROMMET	1	
11	0120902	COVER- Stator	1	
12	49641	DECAL- Output	1	
13	0120901	STATOR	1	
14	0120906	CAPACITOR	1	
15	0120909	HOLDER- Capacitor	1	
16	49831	BREAKER- Circuit (20 amp)	1	
17	0120912	BOLT- Cover (m5)	2	
18	80260	SCREW (120V receptacle)	2	
19	83022	WASHER- Lock	2	
20	84111	WASHER- Flat	2	
21	0120908	BOLT- Rotor	1	
22	0120904	BEARING- Ball	1	
23	0120903	ROTOR	1	
24	80604	SCREW- Hex hd. (3/8-16 x 1")	1	
25	0120916	ADAPTER	1	
	0120914	HARNESS- Wire (not shown)	1	

EH2500 Generator UT-03644 - Wiring Diagram



Rendered by LeadVenture, Inc.