



BOSCH

Battery Vacuum Cleaner

EasyVacuum 12 | 3 603 CD0 080

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description
651	1 619 PA9 899	floor nozzle
651/2	1 619 PA7 502	Roller
651/3	1 619 PA7 501	Shaft
652	1 619 PA9 897	Crevice Nozzle
653	1 619 PA9 896	Brush
654	1 619 PA9 901	Holder
655	1 619 PA9 898	Suction Tube
801	1 619 PB3 790	Dust container
802	1 600 A00 2PS	Filter
803	1 600 A00 2PR	Seal
804	1 619 PB2 300	Filter
851	1 607 A35 07N	Battery Pack PBA 12V, 2,0Ah O-A
869	1 619 PA9 902	Hook
870	1 619 PA5 354	Screw
871	1 619 PA9 046	Extension Tube

Illustration - Type - E

