



Parts List for FS18CS Type 1

Item Number	Part Number	Description	Qty Required
1	5147689-00	LASER ASSEMBLY	1
2	90501991	CLAMSHELL SET	1
3	5147777-00	HOUSING COVER	1
4	5147899-00	UPPER GUARD	1
5	5147900-00	LOWER GUARD	1
6	90502036	MOTOR & GEARBOX	1
7	90502036	MOTOR & GEARBOX	1
8	90502036	MOTOR & GEARBOX	1
9	5149022-00	SHOE ASSEMBLY	1
10	5147707-00	BUMPER GUARD	1
11	5147826-00	CLAMP WASHER	1
12	5148017-00	COVER PLATE	1
13	5148016-00	SPINDLE FILTER	1
14	5148018-00	HOLDER	1
15	5148019-00	SPINDLE LOCK SHAFT	1
16	5148020-00	SPRING,SPINDLE LOCK	1
17	5148160-00	SPINDLE LOCK BUTTON	1
18	5147827-00	BLADE BOLT	1
19	5149023-00	TORSION SPRING	1
20	497479-00	RING,RETAINING	1
21	5148161-00	BAFFLE	1
22	5147898-00	SWITCH	1
23	5148438-00	TRIGGER	1
24	5147897-00	LOCK-OFF BUTTON	1
27	624736-00	ALLEN WRENCH	1
28	5149025-00	RUBBER PLUG	1
29	90501608	FOAM,BAFFLE	2

Parts List for FS18CS Type 1

Item Number	Part Number	Description	Qty Required
32	5148556-00	WASHER TRANS. PVC	1
34	5148783-00	WASHER	1
36	5148557-00	SCREW	1
40	90503101	NUT	2
41	5148755-00	SCREW	4
43	5148739-00	SCREW	6
46	90503562	SELF TAPPING SCREW	1
47	486562-00	SCREW	1
48	90501917	SCREW	5
49	90501918	SCREW	4
51	5148944-00	SPRING,LOCK-OFF	1
52	497557-01	HEX NUT	1
53	5100034-00	TERMINAL BLOCK	1
54	5100035-03	SPRING	2
55	497558-01	BOLT	1
56	5148558-00	BOLT	1
57	5147692-00	COVER	1
58	5147732-00	ADJUSTING SCREW	1
59	90507040	NAME PLATE	1
60	90501268	WARNING LABEL	1
61	90501260	LABEL	1
62	90501259	WARNING LABEL	1
856	90552450	BLADE	1
866	90506197	BATTERY PACK	1
867	5102026-00	BATTERY CAP	1
871	5103069-12	CHARGER	1