



## Parts List for FS18PS Type 1

Item Number	Part Number	Description	Qty Required
1	149518-01	SCREW	1
2	419233-10	KEYLESS CHUCK	1
3	90504405	TRANSMISSION ASSY.	1
4	90504417	FORWARD/REV SELECTOR	1
5	90502293	SCREW	1
7	497283-02	SCREW	3
8	5106167-00	SCREW	2
9	5146421-00	SCREW	2
10	90527171	MOTOR & PINION	1
11	90504416-02	CLAMSHELL SET	1
12	148354-03	BIT CLIP	1
13	419581-01	BIT	1
14	90504402	REAR COVER	1
15	046376-00	PIN	1
16	90526969	VSR SWITCH	1
19	5100035-03	SPRING	2
861	5102001-10	KITBOX	1
866	FS18BX	BATTERY PACK	2
871	5103069-12	CHARGER	1