



Parts List for FS300 Type 3

Item Number	Part Number	Description	Qty Required
1	141883-31	ARMATURE	1
2	141880-71	FIELD	1
3	000000-00	No Longer Available	2
4	000000-00	No Longer Available	1
5	140998-00	HOLDER, BRUSH	2
7	384153-05	SWITCH ASSEMBLY	1
8	330073-98	CORD/8 FT/18-2	1
9	330003-04	BEARING,BALL	1
10	330003-04	BEARING,BALL	2
11	141748-00	TERMINAL	2
13	141736-00	RING, BRUSH	1
14	147431-01	POST,MOUNTING	2
15	000000-00	No Longer Available	1
17	141895-03	PLATE CLMP&BASE	1
18	000000-00	No Longer Available	1
19	330003-64	BALL BEARING	1
21	99359-05	WASHER	4
22	330019-01	SCREW,TORX HD	4
23	142013-00	WASHER	1
25	000000-00	No Longer Available	1
29	000000-00	No Longer Available	1
30	330019-04	SCREW,PLASTITE	8
31	148481-00	PROTECTOR,CORD	1
32	330019-02	SCREW,PLASTITE	2
33	86634-00	CLAMP,CORD,CURV	1
34	000000-00	No Longer Available	1