



Parts List for FS432K-2 Type 1

Item Number	Part Number	Description	Qty Required
1	497014-21	CLAMSHELL SET	1
2	311978-01	F/R ACTUATOR	1
3	148354-03	BIT CLIP	1
4	607918-41	SCREWDRIVER BIT	1
5	000000-00	No Longer Available	1
6	497015-01	TOP COVER	1
7	311979-00	SHIFTER BUTTON	1
8	330013-03	SCREW	4
9	330075-25	KEYLESS CHUCK	1
10	149518-01	SCREW	1
11	311965-01	SHIFTER WIRE	1
12	497018-05	NP:FS432 T1	1
13	000000-00	No Longer Available	1
14	418719-02	MOTOR P PINION	1
15	497026-04	GEARBOX/CLUTCH	1
16	PS120	9.6V BATTERY PACK	1
17	418352-00	PS150 9.6V CHARGER	1
18	330019-00	SCREW	2
19	046376-00	PIN	1
861	000000-00	No Longer Available	1
875	497004-00	LATCH	2