


FLEX[®]



No.	Product Model#	Part Number	Description	Qty
1	FX0451-Z	5660003002	E Ring	2
2	FX0451-Z	3133272001	Handle	1
3	FX0451-Z	5670659001	Pin Shaft	2
4	FX0451-Z	3133302001	Power Cord Clamp	1
5	FX0451-Z	3704866001	Cord Anchorage	4
6	FX0451-Z	3125808001	Rubber Pad	4
7	FX0451-Z	2826263001	Fan	2
8	FX0451-Z	4861020001	Internal Wire Assembly	1
9	FX0451-Z	2829005001	Electric Assembly	1
10	FX0451-Z	2829004001	Lower Housing Assembly	1
11	FX0451-Z	5610265001	Hexagon Lobular Tapping Screw	13
12	FX0451-Z	5610305001	Tapping Screw	2
13	FX0451-Z	2831203001	5387 D02 Electric Assembly	1
14	FX0451-Z	5610011004	Tapping Screw	10
15	FX0451-Z	4861021001	Connecting Seat Wire Assembly	4
16	FX0451-Z	5610098004	Tapping Screw	4
17	FX0451-Z	2825692001	Upper Housing Assembly	1