


FLEX



No.	Product Model#	Part Number	Description	Qty
1	FX1371A	5620039010	Screw	2
2	FX1371A	3127743001	Bit Holder	1
3	FX1371A	2827502002	L R Housing Set	1
4	FX1371A	3707622001	Belt Clip	1
5	FX1371A	3322885001	Rear Cover	1
6	FX1371A	5610241002	Screw	11
7	FX1371A	2751330002	Rotor Set	1
8	FX1371A	2831008001	Electric Assembly	1
9	FX1371A	3131367001	F/R Button	1
10	FX1371A	2790597001	Gear Case Assembly	1
11	FX1371A	5700226001	Steel Ball	2
12	FX1371A	3550206001	Needle Pin	1
13	FX1371A	3521247001	Connecting Lever	1
14	FX1371A	3131282001	Button	1
15	FX1371A	3131267001	Decorative Cover	1
16	FX1371A	3580091001	Bushing	1
17	FX1371A	3660820001	Compression Spring	1
18	FX1371A	5650750001	Washer	1
19	FX1371A	5660134001	Circlips For Shaft	1
20	FX1371A	3127733001	LED Cover	1
21	FX1371A	3707502001	Indicator Label	1
22	FX1371A	3131280001	Switch Button Cover	1