


# FLEX



No.	Product Model#	Part Number	Description	Qty
1	FX5351-Z	3130253453	Volume knob	1
2	FX5351-Z	3130253745	Right Decorative Cover	1
3	FX5351-Z	3130253749	Base	1
4	FX5351-Z	5610361475	Screw	34
201	FX5351-Z	2826622500	Antenna ASSY	1
202	FX5351-Z	2826622502	Rear housing Assy	1
203	FX5351-Z	2826622503	Left Handles Assy	1
204	FX5351-Z	2826622505	Right Handles Assy	1
205	FX5351-Z	2826622504	Left Decorative Cover Assy	1
206	FX5351-Z	2826622506	Battery contact Assy	1