


FLEX



No.	Product Model#	Part Number	Description	Qty
1	FX5471-Z	5610910001	Phillips flat screw	14
2	FX5471-Z	3133658001	motor cable cover	1
3	FX5471-Z	3667809001	stop spring	2
4	FX5471-Z	3133655001	bullet	2
201	FX5471-Z	2831284001	Motor PCBA	1
202	FX5471-Z	2828998001	Adapter Holder Assembly	1
5	FX5471-Z	4810398001	Adapter	1
6	FX5471-Z	3133657001	Chute	1
7	FX5471-Z	3133644001	upper casing	1
8	FX5471-Z	5610911001	Phillips pan head screw	20
9	FX5471-Z	5610909001	screw with washer	2
10	FX5471-Z	3133674001	Crimping cover	1
11	FX5471-Z	3133649001	Tilt limiter	2
12	FX5471-Z	5650956001	Flat Washers	2
13	FX5471-Z	5640490001	Cushioned screw	2
14	FX5471-Z	3133648001	Left and right decorative covers	2
15	FX5471-Z	3650306001	right hook	1
16	FX5471-Z	3133708001	wall mat	2
17	FX5471-Z	3133647001	right bracket	1
18	FX5471-Z	3133646001	right side panel	1
19	FX5471-Z	5610908001	Flat head screw	16
20	FX5471-Z	3133654001	right base	1
21	FX5471-Z	4810397001	Extension cord	1
203	FX5471-Z	3403414001	backplane assembly	1
22	FX5471-Z	3133669001	decorative panel	1
23	FX5471-Z	3133645001	left base	1
24	FX5471-Z	2245724001	panel stickers	1
25	FX5471-Z	3133719001	TYPE-C cover	1
26	FX5471-Z	3133668001	Button	1
204	FX5471-Z	2828990001	Potentiometer Assembly	1
27	FX5471-Z	3133683001	knob	1
28	FX5471-Z	3133643001	left panel	2
29	FX5471-Z	3133642001	left bracket	1
30	FX5471-Z	3650305001	left hook	1
31	FX5471-Z	3133684001	front grille	1
32	FX5471-Z	3133687001	Fan Locking Knob	1
33	FX5471-Z	3133685001	Fan Blade	1
205	FX5471-Z	2828997001	DC Motor Components	1
34	FX5471-Z	4861079001	Cable	1
35	FX5471-Z	3133686001	rear grille	1