




Parts Manual

GP6500E 389CC (Models 0059413 & 0065150)

NOTICE!

The information in this manual is known to be accurate as of the date of release shown on the cover. However, engineering changes can occur without notice. To obtain the proper parts, please be sure to use the serial number of the unit being serviced when ordering from this manual. Always refer to any parts notes and changes before ordering. All other parts not shown in this manual can be found on Generac's exploded view drawings online on GENservice at www.generac.com.



GP6500E



Item	Part #	Qty	Description
1	0H97480ST03	1	PANEL RAIL C/PNL SIDE
2	0H91980159	8	SCREW, PAN, M5 X 16
3	0H1780	6	BOLT, CURVED HEAD, M8X40
4	0H9775E	1	PANEL ASSY., CONTROL
5	0G9391	1	COVER, OUTLET
6	0J4536A	1	FACE PLATE GP PORTABLE ES
7	0G8758	1	SOCKET
8	0J86620108	6	NUT, M4
9	0H0265E	2	BREAKER, CIRCUIT, 30A
10	0H0265C	2	BREAKER, CIRCUIT, 20A
11	0G9392	2	COVER, OUTLET
12	0G8321	1	METER, HOUR
13	0J0251	1	SWITCH, ENGINE
14	0D4968	2	SOCKET
15	0G9756A	1	COVER, PANEL BACK
16	067989	4	NUT, M8
17	0J06940ST15	1	BRACKET, BATTERY
18	0G84420194	3	BOLT, M6X12
19	0G9449	1	BATTERY
20	0G8442C113	1	GRIP, HANDLE
21	0H97560ST15	1	HANDLE
22	0J5347	1	BUTTON, SNAP
23	0H9760	1	CAP, END
24	0H1782	9	NUT, LOCKING CAP, M8
25	0H97670ST15	1	BRACKET, HANDLE
26	0B1214	5	BOLT, M8X45
27	0H1781	2	BOLT, CARRIAGE HEAD M8X46
28	0J02460ST15	1	FRAME
29	0G84420107	4	NUT, M10
30	0H1783	4	MOUNT, RUBBER VIB
31	0K0097	2	FRAME, BENT FOOT
32	0K0098	4	NUT, M8
33	0K0099	2	FOOT, RUBBER
34	0K0100	2	BOLT, M6X28
35	0K0105	2	NUT, M6
36	0H0204	2	PIN, AXLE
37	0K6011	2	WHEEL
38	0D4999	2	PIN, COTTER
39	022304	2	WASHER, FLAT 13X2
40	0J35220156	1	BOLT, M6X20
41	0K0093	1	WASHER, SPECIAL LOCK
42	0G84420272	1	NUT, M6
43	0J47870118	1	WASHER, FLAT 6X0.8

Item	Part #	Qty	Description
44	0K0094	1	NUT, M6
45	0K0092	1	WIRE ASSY., GRND
46	0J86620104	1	BAFFLE
47	0K1291	1	ALTERNATOR ASSY.
48	0H0919	1	BRUSH, ALTERNATOR
49	0J6072	1	TERMINAL
50	070264	1	WASHER, FLAT, M10X4
51	0H91980158	2	BOLT, FLANGE, M5X220
52	0H2579B	1	AVR
53	0H3049	1	COVER, GEN-END
54	0J4967	8	BOLT, M5X12
55	0J4968	3	BOLT, M5X16
56	0J86620103	1	BOLT, M10X275
57	0H12810104	4	BOLT, M6X185
58	0H91980171	1	HOUSING, REAR BEARING
59	0H1411B	4	RUBBER, FUEL TANK
60	0H1610A	4	LINING, ANTI-CRUSH
61	0E9507C	4	BOLT, M8X20
62	0H1326	1	FILTER, FUEL
63	0H0958	1	CAP, FUEL
64	0K09150112	1	FUEL GAUGE
65	0H7510A0SRV	1	TANK, FUEL, 7 GAL
66	0J0974	1	VALVE FUEL SHUTOFF
67	0J7921	1	ROLL OVER VALVE
68	0H9749AST03	1	PANEL RAIL BACK
69	0E9507B	2	BOLT, M8X25
70	0J4691	1	GASKET, EXH., MUFFLER
71	0H9763A	1	MUFFLER
72	0E9470	4	BOLT, M8X16
73	0G8542	1	BRACKET, MUFFLER
74	0K0091	1	HOSE FORMED ROV-AIRBOX
75	0J35220173	1	CLAMP, 012
76	0J35220174	4	CLAMP, 010
77	0G9757A	1	HOSE, FUEL, 08X55
78	0G9914	1	FILTER, FUEL
79	0G9757B	1	HOSE, FUEL, 08X80
80	0J25910115	4	CLAMP, HOSE, 09
81	0G8442E	1	ENGINE 389CC, ES, W/O MUFFLER
82	0H98380101	1	MOTOR, STARTER
83	0H98380102	1	RELAY, STARTER
84	0J4535A	1	MANIFOLD, EXHAUST
85	0J35220161	2	NUT, M8



GP6500E

Item	Part #	Qty	Description
86	0G9028	1	GASKET, EXH, CYLNDR
87	0J00620100	1	BOLT, M5X10
88	0H9761	1	SCROLL, ALTERNATOR
89	0G8442C112	1	BRACKET, AIR CLEANER
90	0J4157B	1	CABLE, BATTERY, POS. (RED)
91	0J4157A	1	CABLE, BATTERY, NEG. (GREEN)
92	0H3535	2	NUT, M5
93	0G5744	1	CHARGER, BATTERY.
94	0J4959	1	INPUT ASSY., 12VDC CHARGER

©2013 Generac Power Systems, Inc. All rights reserved.
Specifications are subject to change without notice
No reproduction allowed in any form without prior written consent from Generac Power Systems, Inc.