



BOSCH

Dust Extraction

GDE 18V-12 | 1 600 A02 BV8

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	Illustration
1	1 605 108 2SB	Housing Section	1
4	1 607 233 5PG	Electronic Module	1
6	1 605 500 2KB	Housing Cover	1
7	1 600 A02 B2N	Cover	1
17	1 600 A02 B2H	Hose	1
18	1 600 A02 B2G	Elbow	1
19	1 600 A02 B2K	Angle Piece	1
20	1 600 A02 B2J	Aluminum Profile	1
21	1 600 A02 B2L	Toothed rack	1
22	1 600 A02 B2M	End cap	1
23	1 600 A02 F7U	Button	1
24	1 600 A02 B35	Seal Element	1
25	1 600 A02 R8S	Seal Element	1
29	1 601 11C 4S0	Socket Pipe	1
30	1 605 411 02X	Dust container	1
75	2 914 201 465	Torx Oval-Head Screw	1
77	1 603 435 07C	Torx Oval-Head Screw	1
85	1 600 A02 B34	Lens	1
86	1 600 A02 B31	Latch-Type Plug	1
87	1 600 A02 B2Z	Push Button	1
88	1 600 A02 B30	Push Button	1
89	1 614 643 025	Compression Spring	1
90	1 600 210 0AC	O-Ring	1
802	1 619 PC1 007	DC motor	1
809	1 619 PC1 009	Label	1
822	1 600 A00 D2R	Brush Ø35mm	1
822	1 600 A02 B32	Brush	1
826	1 600 A02 AW8	Filter	1
826	2 608 000 717	Filter	1

Illustration - Type - E

