



BOSCH

Random orbital sander

GEX34-6 | 3 601 C7B 210

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list

Item	Part Number	Description	Illustration
1	2 605 105 964	Housing Section BLUE	1
2	2 604 220 744	Field 110-127V	1
3	2 604 011 436	Armature 110-127V	1
3/13	2 600 905 051	groove ball bearing 7x19x6	1
3/6	2 606 610 076	Fan	1
4	2 607 200 689	Switch	1
5	2 604 460 240	Power supply cord USA/CAN/ SMA 4,15m 2 x 0,82mm SJ 18/2	1
6	2 600 703 070	Grommet Ø7,3-Ø8,6x120 MM	1
9	1 601 11C 3TN	Manufacturer's nameplate GEX34-6	1
14	2 600 905 034	groove ball bearing	1
16	2 604 337 003	Brush Holder	1
19	2 603 490 017	Torx Oval-Head Screw 3x10	1
20	2 601 111 477	Reference Plate	1
21	2 600 283 022	Suction Hood	1
22	2 601 328 091	Suction Piece	1
23	2 601 328 090	Suction Piece	1
24	1 600 A00 RD6	Special Screw	1
25	2 603 435 096	Torx Oval-Head Screw M3x10	1
30	2 600 100 041	Plain Washer DIN 315-M8-GT-C	1
33	2 600 206 028	Friction Ring	1
34	2 608 614 075	Backing Pad Ø150	1
35	1 600 A01 5G7	Hex Socket Head Cap Screw	1
37	2 603 435 086	Tapping Screw	1
38	2 601 329 053	Contact Strap	1
40	2 603 435 042	Thread-forming tap. Screw	1
42	2 604 448 368	Connecting Cable	1
43	2 603 203 041	Damping Element	1
44	1 607 233 440	Speed governor 100-120V	1
45	2 915 121 006	Square Nut DIN 562-M6-04	1
46	2 603 490 023	Torx Oval-Head Screw 4x20	1
47	2 605 500 208	Housing Cover	1
48	2 603 490 022	Screw 4x16	1
655	2 605 411 234	Dust Chamber	1
656	2 602 026 175	Auxiliary Handle BLACK	1

Spare parts list

Item	Part Number	Description	Illustration
657	2 607 950 059	Offset Screwdriver	1
808	1 601 11A 82E	Nameplate	1
811	1 607 014 117	Carbon Brush	1
826	1 600 A02 30T	Fan	1
836	2 605 105 966	Motor Housing BLUE	1

Illustration - Type - E

