



Parts List for GH750-B2 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|-----------------|--------------|
| 1 | 90517154 | CLAMSHELL ASSY. | 1 |
| 2 | 588037-00 | SWITCH | 1 |
| 3 | 90517189 | TRIGGER | 1 |
| 4 | 244053-00 | SPRING, TRIGGER | 1 |
| 5 | 90517157 | TUBE ASSY | 1 |
| 6 | 90532945 | HANDLE ASSEMBLY | 1 |
| 7 | 90540668 | POWER CORD | 1 |
| 10 | 90517166 | CLAMSHELL ASSY. | 1 |
| 11 | 90542804 | MOTOR ASSEMBLY | 1 |
| 13 | 90522536 | LEADWIRE ASSY. | 1 |
| 14 | 821070 | CORD CLAMP | 1 |
| 15 | 90515608 | EDGE BUTTON | 1 |
| 16 | 580936-00 | SPRING | 1 |
| 17 | 90514753 | GEAR ASSY. | 1 |
| 18 | 90517168 | GUARD ASSEMBLY | 1 |
| 19 | 90550257 | GUARD | 1 |
| 20 | 90517174-01 | EDGE GUIDE | 1 |
| 21 | 90514754 | SPOOL COVER | 1 |
| 22 | 90517175 | SPOOL & LINE | 1 |
| 23 | 747329 | SCREW | 20 |
| 24 | 90515051 | LINER | 1 |
| 25 | 373158 | SCREW | 1 |
| 26 | 90518277 | PLUG ASSY. | 1 |
| 27 | 90540669 | NAME PLATE | 1 |
| 28 | 90522373 | WARNING LABEL | 1 |
| 30 | 90532945 | HANDLE ASSEMBLY | 1 |
| 31 | 90539049 | KNOB ASSEMBLY | 1 |

Parts List for GH750-B2 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|---------------|--------------|
| 32 | 151710-00 | SCREW | 1 |
| 33 | 330015-02 | NUT,HEX | 1 |
| 34 | 243805-00 | BLADE | 1 |
| 35 | 681914-00 | SCREW | 2 |
| 36 | 90541507 | WARNING LABEL | 1 |
| 37 | 90548553 | LEVER | 1 |