



Parts List for GL300-AR Type 4

Item Number	Part Number	Description	Qty Required
1	5140129-95	POWER CORD	1
2	5140129-61	CORD PROTECTOR	1
3	5140129-62	SCREW	4
4	5140129-63	CORD CLAMP	2
5	5140129-66	HOSE	1
6	5140129-65	SWITCH	1
7	5140129-64	TRIGGER SWITCH	1
8	5140129-96	LEFT HOUSING	1
9	5140129-97	HOLDER ASSY.	1
10	5140129-98	CONNECTOR	1
11	5140129-99	DIAL	1
12	5140130-00	SCREW	1
13	5140130-01	BLOCK	1
14	5140130-02	BLOCK	1
15	5140130-03	SPRING	1
16	5140130-04	TUBE ASSY	1
17	5140130-05	KNOB ASSY.	1
18	5140130-06	LEFT HOUSING	1
19	5140130-07	MOTOR ASSY	1
20	5140130-08	FAN	1
21	5140130-09	HEX NUT	1
22	5140130-10	COVER	1
23	5140129-85	SPRING	1
24	5140129-86	SPOOL,SA	1
25	5140129-87	SPOOL COVER	1
26	5140129-84	GUARD ASSEMBLY	1
27	5140130-11	BLADE	1

Parts List for GL300-AR Type 4

Item Number	Part Number	Description	Qty Required
28	5140130-12	SCREW	1
29	5140130-13	RIGHT HANDLE	1
30	5140129-88	SCREW	16
31	5140129-73	HEX NUT	1
32	5140130-14	RIGHT HOUSING	1
33	5140129-78	RUBBER	1