



Parts List for GL300P-B2 Type 2

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------|--------------|
| 1 | 5140018-69 | SPOOL CAP | 1 |
| 2 | 5140018-70 | SPOOL HOLDER | 1 |
| 3 | 5140018-71 | SPOOL | 1 |
| 4 | 5140018-72 | SPRING | 1 |
| 5 | 5140018-73 | SPOOL HOUSING | 1 |
| 6 | 5140018-74 | GUARD | 1 |
| 7 | 5140018-65 | MOTOR | 1 |
| 8 | 5140018-75 | HOUSING,LH | 1 |
| 9 | 5140076-29 | SCREW | 1 |
| 10 | 5140076-30 | FLAT WASHER | 1 |
| 11 | 5140076-31 | INSERT | 1 |
| 12 | 5140076-32 | INSERT | 1 |
| 13 | 5140018-82 | TERMINAL | 1 |
| 14 | 5140076-33 | SLEEVE | 1 |
| 15 | 5140018-86 | CONNECTOR ASSY | 1 |
| 16 | 5140018-87 | SWITCH | 1 |
| 17 | 5140018-91 | CORD CLAMP | 1 |
| 18 | 5140018-92 | CORD PROTECTOR | 1 |
| 19 | 5140018-88 | HOUSING,LEFT | 1 |
| 20 | 5140018-89 | GEL PAD | 1 |
| 21 | 5140018-97 | CORD SET | 1 |
| 22 | 5140018-94 | ACTUATOR | 1 |
| 23 | 5140018-93 | HOUSING, RH | 1 |
| 24 | 5140076-34 | NUT | 1 |
| 25 | 5140018-96 | HOUSING,RIGHT | 1 |
| 26 | 5140076-35 | RUBBER BUMPER | 1 |