



Parts List for GS300S Type 3

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|---------------------|--------------|
| 1 | 330013-02 | SCREW,PLASTIC | 6 |
| 2 | 000000-00 | No Longer Available | 1 |
| 3 | 242642-02 | PLATE | 1 |
| 4 | 243135-00 | BLADE | 1 |
| 5 | 91247-00 | GEAR | 1 |
| 7 | 680945-00 | SCREW | 2 |
| 9 | 000000-00 | No Longer Available | 1 |
| 10 | 000000-00 | No Longer Available | 1 |
| 11 | 000000-00 | No Longer Available | 1 |
| 13 | 000000-00 | No Longer Available | 1 |
| 15 | 000000-00 | No Longer Available | 1 |
| 16 | 233304-00 | NAMEPLATE-SHEET | 1 |
| 17 | 91246-00 | GEAR & PINION | 1 |
| 18 | 000000-00 | No Longer Available | 1 |
| 19 | 000000-00 | No Longer Available | 1 |
| 20 | 000000-00 | No Longer Available | 1 |
| 23 | 33314-00 | CONNECTOR | 4 |
| 25 | 099047-01 | BALL | 1 |
| 27 | 380657-00 | LABEL,WARNING | 1 |