



**BOSCH**

# Percussion Drill

GSB 16 | 3 601 B18 080

---

## Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description
1	2 609 100 419	Housing
2	2 604 220 647	Field 230V
5	2 604 460 245	Power supply cord CN 220V 2,65m 2 x 0,75mm H05 VV-F
6	2 600 707 059	Grommet Ø6,9 MM
13	2 609 110 153	Ball Bearing 8x22x7
14	2 609 110 491	Ball Bearing
22	2 910 611 002	Tapping Screw DIN 7981-ST2,2x9,5-C-H
32	1 903 230 010	Ball DIN 5401-5,5MM-III-ST
33	2 600 905 068	groove ball bearing 15x32x9
34	2 609 199 115	Bearing Bracket
36	2 609 110 449	Drilling Spindle
37	2 606 320 092	Conversion Gear
40	2 600 100 105	Plain Washer
41	2 604 616 006	Compression Spring
48	2 609 110 627	Spring Clip
67	2 609 110 481	Spring retaining ring
654	2 602 025 094	Auxiliary Handle
655	2 609 005 615	Depth-Gauge
803	2 609 120 235	Armature 220-240V
804	2 609 199 663	Switch
810	2 607 014 013	Carbon-Brush Set
831	2 609 160 127	Change-Over Switch
836	2 609 160 124	Drilling Spindle
839	1 608 571 080	Key Chuck Ø1,5-13 MM
839/7	2 607 950 007	Chuck Wrench SG2
892	2 603 490 022	Screw 4x16
893	2 601 035 001	Cable Clip
895	3 605 430 003	Grease Tube Albida

Illustration - Type - E

