



BOSCH

Percussion Drill

GSB 16 RE | 3 601 B18 180

Table of Content

| | |
|--------------------------|---|
| Spare parts list..... | 2 |
| Illustration - Type..... | 3 |

Percussion Drill | GSB 16 RE | 3 601 B18 180

Spare parts list

| Item | Part Number | Description |
|-------|---------------|-----------------------------------------------------|
| 1 | 2 609 100 579 | Housing |
| 2 | 2 604 220 647 | Field 230V |
| 4 | 1 607 200 270 | Switch BLACK |
| 5 | 2 604 460 245 | Power supply cord CN 220V 2,65m 2 x 0,75mm H05 VV-F |
| 6 | 2 600 707 059 | Grommet Ø6,9 MM |
| 13 | 2 609 110 153 | Ball Bearing 8x22x7 |
| 14 | 2 609 110 491 | Ball Bearing |
| 16 | 2 604 337 059 | Brush Plate |
| 22 | 2 910 611 002 | Tapping Screw DIN 7981-ST2,2x9,5-C-H |
| 25 | 2 609 100 580 | Lever |
| 32 | 1 903 230 010 | Ball DIN 5401-5,5MM-III-ST |
| 33 | 2 600 905 068 | groove ball bearing 15x32x9 |
| 34 | 2 609 199 115 | Bearing Bracket |
| 36 | 2 609 110 449 | Drilling Spindle |
| 37 | 2 606 320 092 | Conversion Gear |
| 40 | 2 600 100 105 | Plain Washer |
| 41 | 2 604 616 006 | Compression Spring |
| 48 | 2 609 110 627 | Spring Clip |
| 55 | 2 609 120 221 | Connecting Cable WHITE |
| 56 | 2 609 120 222 | Connecting Cable RED |
| 67 | 2 609 110 481 | Spring retaining ring |
| 654 | 2 602 025 094 | Auxiliary Handle |
| 655 | 2 609 005 615 | Depth-Gauge |
| 803 | 2 609 120 235 | Armature 220-240V |
| 810 | 2 607 014 013 | Carbon-Brush Set |
| 831 | 2 609 160 127 | Change-Over Switch |
| 836 | 2 609 160 124 | Drilling Spindle |
| 839 | 1 608 571 080 | Key Chuck Ø1,5-13 MM |
| 839/7 | 2 607 950 007 | Chuck Wrench SG2 |
| 892 | 2 603 490 022 | Screw 4x16 |
| 893 | 2 601 035 001 | Cable Clip |
| 895 | 3 605 430 003 | Grease Tube Albida |

Illustration - Type - E

