



BOSCH

Cordless Screwdriver

GSR 18-2-LI | 3 601 JB7 380

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Cordless Screwdriver | GSR 18-2-LI | 3 601 JB7 380

Spare parts list

Item	Part Number	Description	
1	2 609 101 065	Housing	BLUE
4	1 607 233 544	Electronics Module	18V
5	2 609 101 009	Adjusting lever	
9	2 609 134 164	Manufacturer's nameplate	GSR 18-2-LI
25	2 609 111 562	Keyless Chuck	
32	2 609 199 279	Switchover Unit	
45	2 609 199 786	Gear Box	
46	1 609 280 477	Compression Spring	
47	2 609 100 858	Lens	
91	1 607 A35 0MA	Battery Pack	GBA 18V 2.0Ah
91/1/22	2 601 115 537	Sticker	
100	2 609 110 956	Clip	
101	2 609 110 538	Screw	
103	2 609 110 835	Nut	
105	2 609 110 834	Screw	
107	2 603 421 229	Countersunk-Head Screw LEFTHAND THREADS	M6x23
109	2 609 110 342	Screwdriver Blade	
653	2 607 225 427	Fast Charger	AUS 240/10,8-18V, 1h
653	2 607 225 431	Fast Charger	RC 115/10,8-18V, 1h
653	2 607 225 439	Fast Charger	CN 220/10,8-18V, 1h
802	2 609 199 591	DC motor	14,4V-18V
804	1 609 280 478	Contact retainer	

Illustration - Type - E

3 601 JB7 300
 Stand | 18-11
 Issue | 17-07-11

Fig./Abb. 1

