



BOSCH

Cordless Screw Driver

GTB 185-LI | 3 601 JK7 080

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	
1	1 600 A02 4AZ	Housing	
2	1 619 P16 440	Stator	
4	1 607 233 5N0	Speed governor	
5	2 607 202 902	Switch	
6	1 600 A01 D6X	Lever Switch	
7	2 600 590 006	Ratchet Cap	
9	1 601 11C 4D9	Manufacturer's nameplate	
11	1 601 11C 41N	Sticker	
12	1 600 A02 61R	Separator	
45/20	1 600 A01 A4D	Depth-Gauge	
45/30	1 618 597 13F	Toolholder	
46	1 609 280 477	Compression Spring	
48	2 609 110 838	Clip	
91	1 607 A35 0MA	Battery Pack	GBA 18V 2.0Ah
91	1 607 A35 0MD	Battery Pack	TWN GBA 18V 2.0Ah
101	2 609 110 201	Torx Flat-Head Screw	3x16
102	2 603 490 022	Screw	4x16
650/1	2 609 111 584	Clip	
650/2	2 609 110 834	Screw	
653	2 607 226 283	Fast Charger 2A / 12-18V	UK GAL 18V-20 220-240V /
653	2 607 226 289	Fast Charger	LAM GAL18V-20
803	1 607 000 E6G	Rotor	
808	1 601 11A 8M6	Nameplate	
810	1 607 000 E6H	Friction Washer	
845	1 607 000 E6J	Gear Unit	
845/10	1 607 000 E6K	Gear Housing	
850	1 607 000 E9S	Planet Gear	

Illustration - Type - E

