



HCP80 Plate Compactor UT-06042 - Eccentric



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context	Note
1	4990436	KEY- Parallel	1		
2	4990435	CLUTCH- Centrifugal	1		
3	4990437	WASHER- Plate 5/16"	1		
4	4990438	WASHER- Spring 5/16"	1		
5	4990439	BOLT- Hex 5/16 x 11/2"	1		
6	4990456	BELT- V	2		
7	4990453	BOLT- Hex (m14 x 30")	1		
8	4990452	WASHER- Spring (m14)	1		
9	4990451	WASHER- Plate	1		
10	4990450	PULLEY- V	1		
11	4990446	BOLT- Hex (m8 x 20)	12		
12	4990417	WASHER- Spring (m8)	12		
13	4990445	HOLDER- Bearing	1		
14	4990444	SEAL- Oil	1		
15	4990443	GASKET	1		
16	4990447	BEARING	2		
17	4990449	KEY- Parallel (10 x 8 x 25)	1		
18	4990448	VIBRATOR UNIT	1		
19	4990441	CASE- Vibrator Unit	1		
20	4990454	GASKET	1		
21	4990442	HOLDER- Bearing	1		
22	4990403	WASHER- Spring (m16)	1		
23	4990455	GAUGE- Oil level	1		

HCP80 Plate Compactor UT-06042 - Vibration Plate



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	
1	4990402	PLATE- Vibration	1	
2	4990403	WASHER- Spring (m16)	4	
3	4990404	BOLT- Hex (m16 x 65)	4	
4	4990412	ABSORBER- Shock	4	
5	4990408	NUT- Hex (m12)	8	
6	4990407	WASHER- Plate (m12)	8	
7	4990459	DECAL- Caution	1	
8	4990406	WASHER- Plate (m12)	4	
9	4990409	SPRING- Earth	1	
10	4990411	WASHER-Spring (m10)	4	
11	4990433	BOLT-Hex (m10 x 25)	4	
12	4990432	COVER- Belt	1	
13	4990421	BOLT- Hex (m10 x 45)	1	
14	4990422	NUT- Hex (m10)	1	
15	4990419	CAP	1	
16	4990418	NUT- Hex (m8)	4	
17	4990417	WASHER- Spring (m8)	4	
18	4990416	WASHER- Plate (m8)	4	
19	4990415	SEAT- Engine	2	
20	4990414	COVER- Vibration Plate	1	
21	4990423	ABSORBER- Shock (OT-9)	2	Use thread locking compound P/N 23488C to secure bolts in place
22	4990420	ABSORBER- Shock	2	Use thread locking compound P/N 23488C to secure bolts in place
23	4990428	HANDLE	1	
24	4990430	PIN- Bracket	2	Use thread locking compound P/N 23488C to secure bolts in place
25	4990429	RUBBER- Handle	2	