



Parts List for HD500-AR Type 1

Item Number	Part Number	Description	Qty Required
1	5140028-80	CHUCK SCREW	1
2	5140028-81	CHUCK	1
3	5140030-74	SHAFT	1
4	5140028-83	SPRING	1
5	5140028-84	BALL BEARING	1
6	5140028-85	WASHER	1
7	5140028-86	GEAR	1
8	5140028-87	COVER	1
9	5140028-88	STEEL BALL	1
10	5140028-89	SUPPORT FRAME	1
11	5140028-90	BALL BEARING	1
12	5140028-91	ARMATURE 220V	1
13	5140028-92	BALL BEARING	1
14	5140028-93	LOCK ASSY	1
15	5140028-94	KNOB ASSY.	1
16	5140028-95	FIELD 220V	1
17	5140028-96	BRUSH CAP	2
18	5140028-97	BRUSH,CARBON	2
19	5140030-75	BUSHING	2
20	5140028-98	SUPPORT, BRUSH	2
22	5140029-00	CLAMP,CABLE	1
23	5140029-01	SWITCH,MAIN	1
25	5140029-02	CORD PROTECTOR	1
26	5140029-03	HOUSING COVER	1
27	5140029-04	HOUSING	1
28	5140029-05	SCREW	10
29	5140029-06	SCREW	2

Parts List for HD500-AR Type 1

Item Number	Part Number	Description	Qty Required
30	5140029-07	CORD & PLUG	1
32	5140030-76	SIDE HANDLE	1
33	5140030-77	DEPTH GAUGE	1
40	187455-00	RATING PLATE	1
41	5140030-85	BRAND LABEL	1
861	5140030-84	KIT BOX	1