


# HG3510 Series Electric Generator - General Assembly



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	310222003	Carrier, assembly	1	Homelite Consumer Products, Inc., will not provide engines as placement parts. Engines are covered through the engine manufacturer's warranty. Consult the accompanying engine manual or contact our service department for assistance.
2		Engine Subaru OHC	1	
3	570356001	Isolator	4	These are standard parts available at your local hardware store.
5	660599002	Bolt whz 5/16-24 x .63	4	
8	660599003	Bolt, hex 5/16-24 x 7.75	1	
9		Washer, lock 5/16	3	
11	661302001	Bolt, HWH 1/4-20 x 5.50	1	
12	638703001	Lug, ground	1	
13	678016006	Nut, nyloc 1/4-20	4	
14		Bolt, 5/16-18 x 1-1/4	1	
15	678145002	Nut, hex flg 5/16-18	6	
16	678259003	Nut, nyloc 5/16-18	2	
17	290404001	Assembly, ground wire	4	These are standard parts available at your local hardware store.
18		Washer, star external 5/16	7	
19		Bolt, hex 5/16-18 x 3/4	1	These are standard parts available at your local hardware store.
20	678672001	Spacer .38 ID	2	These are standard parts available at your local hardware store.
21	309323001	Muffler	2	
22	901687001	Gasket	1	
23		Bolt, 5/16-18 x 1 1/2	1	
24	290403003	Panel, wired	1	
25	660598001	Screw #6-20 x .38 Type B	1	
26	638497002	Shield, heat	2	
27		Fuel tank assembly	1	
27A	661519002	Fuel Gauge/Screws	2	
27B	519710001	Strainer Basket	4	
27C	310720002	Fuel Cap	1	
27E	519711001	Fuel shut off valve with filter	1	Contact your nearest Homelite(R) Service Center for replacement fuel tanks.
28		Bolt, 1/4-20 x 1	1	
				These are standard parts available at your local hardware store.

Ref #	Part #	Description	Qty	Context Note
29		Washer, flat 5/16	4	These are standard parts available at your local hardware store.
30	519728001	Spacer, handle bracket	2	
31	310224003	Handle	1	These are standard parts available at your local hardware store.
32		Bolt, 5/16-18 x 2	1	
33	678654001	Nut whz 8mm	1	
34	570356002	Isolator	1	
35	310223002	Wheel	3	
36		Bolt, 5/16-18 x 1.00	2	These are standard parts available at your local hardware store.
37	638706001	Foot rubber	2	These are standard parts available at your local hardware store.
38		Washer, flat 3/8	2	
39	310715001	Lanyard	2	
40	660597002	Screw, #10 x .75	1	These are standard parts available at your local hardware store.
41		Bolt, 3/8-16 x 4.25	4	
42	678659001	Nut, nyloc 3/8-16	2	
43	678672002	Spacer .38 ID	2	
44	310712001	Pin, release	2	These are standard parts available at your local hardware store.
45	519712001	Cap, plastic	1	
46	290412002	Assembly, ground wire	2	
47	661300001	Screw HSW #8 x .38	1	
48		Bolt, 1/4-20 x 1.50	1	
49		Washer, flat 1/4	2	These are standard parts available at your local hardware store.
50	678505003	Bracket, foot	2	(Not Shown)
51	678655001	Cord retainer	2	
52	638682002	Screen, spark	2	
	310227008	Generator Head Assembly	1	
	987000365	Operator's Manual	1	
	900906006	Bottle of Lubricant (10W30)	1	
	310725001	Fuel Line Assembly (PMC433500)	1	
	310724001	Assembly, Carbon Cannister Hose(PMC433500)	1	
	310722001	Assembly, Carbon Cannister	1	

<b>Ref #</b>	<b>Part #</b>	<b>Description</b>	<b>Qty</b>	<b>Context Note</b>
		(PMC433500)		
	310723001	Carbon Canister, 380CC, Sentec	1	(Not Shown)
	310721001	Rollover Valve, Direct Mount, Sentec	1	(Not Shown)
	570363001	Bushing, Rollover Valve, Sentec	1	(Not Shown)
	940705031	Logo Label	1	(Not Shown)
	940707008	Danger Label	1	(Not Shown)
	940974007	Risk of Fire Danger Label	1	(Not Shown)
	940513008	Ground Warning Label	1	(Not Shown)
	940680021	Hot Surface Label	1	(Not Shown)
	940514005	Lock Pin Label	1	(Not Shown)
	940708007	Lubricant Label	1	(Not Shown)
	940617032	Starting Label	1	(Not Shown)
	961030005	Danger Hang Tag	1	(Not Shown)
	940513005	Ground Label	1	(Not Shown)
	940617032	Quick Start Label	1	(Not Shown)