



HGE3500A Generator UT-03623-A - Generator & Control Box



Ref #	Part #	Description	Qty	Context Note
1	5375225	END BELL-Generator	1	
2	81053	NUT-Hex (1/4-20")	4	
3	83117	WASHER-Lock Int./Ext.	4	
4	80187	SCREW-Hex Hd. (3/8-16 X 7/8")	4	
5	A49127AS	STATOR & SHELL	1	
6	46840	TIE CABLE	4	
7	A49099S	ROTOR	1	
8	53819	BEARING	1	
9	537592	BRUSH HEAD	1	
10	830771	WASHER-Lock Int. (.035 thick)	4	
11	4885209	BOLT-Rotor	1	
12	53760	BRUSH HOLDER	1	
13	80260	SCREW-Mach. (8-32 X 3/8")	2	
14	53762	BRUSH	2	
15	82474	SCREW-Thd. Form. (8-32)	7	
16	53818	RECTIFIER	2	
17	82205	SCREW-Thd. Form. (8-32 X 3/4")	3	
18	513941	COVER-Brush Head	1	
19	83022	WASHER-Lock Int. (#8)	5	
20	80085	SCREW-Hex Cap (5/16-18 X 1")	1	
21	4885304	BOLT-Stator	4	
22	83002	WASHER-Lock (5/16")	1	
23	84058	WASHER-Flat (5/16")	1	
24	A53769	FAN	1	
25	A49271	PANEL COVER (Inc. #27)	1	
26	80577	SCREW-Pan Hd. (8-32 X 3/8")	14	
27	81015	NUT-Wing (5/16-18")	1	
28	81009	NUT (8-32)	10	
29	83060	WASHER-Lock (#8)	10	
30	49298	BREAKER-Circuit (D.C.)	1	
31	A48999D	VOLTAGE REGULATOR	1	
32	42366	BLOCK TERMINAL	1	
33	49368	CLAMP-Cable	1	
34	48952	BREAKER-Circuit (A.C.) (includes Nut)	1	
35	46508	RECEPTACLE-Locking (L14-20R)	1	
36	04058	RECEPTACLE- Duplex (GFCI) (5-15R)	2	
37	A01687	PANEL-Control	1	
38	49613	DECAL-Warning	1	
39	A49380	LEAD-D.C.	1	
40	49748	SCREW-Pan Hd. (1/4-20 X 3/4)	4	
41	49351	GROMMET-Isolator	4	
42	84110	WASHER-Flat (#10)	2	
43	49472	VOLTMETER	1	
44	A49365	PILOT LIGHT (Red) (includes Nut & Washer)	1	
45	A49366A	PILOT LIGHT (Green) (includes Nut & Washer)	1	

Ref #	Part #	Description	Qty	Context Note
46	00533	BANANA JACK (Black)	1	
47	00525	BANANA JACK (Red)	1	
48	49299	SWITCH-Rocker	1	
49	80582	SCREW-Pan Hd. (#8-32 X 5/8")	2	
50	81018	NUT-Hex (5/16-18")	1	
51	84025	WASHER	4	
52	01583	WASHER-Insulating	2	
53	01582	WASHER-Shoulder	2	

HGE3500A Generator UT-03623-A - Muffler & Frame




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	81162	NUT- (5/16-18")	10	
2	83081	WASHER-Lock Int.	12	
3	49367	ISOLATOR- Vibration	4	
4	49412	PIN-Cottor Hair	4	
5	82206	SCREW-Hex Tapping (5/16-18 X 1")	2	
6	83081	WASHER-Lock Int.	4	
7	48944	SUPPORT-Generator	1	
8	A49399	GROUND STRAP	1	
9	49265	SUPPORT-Engine	1	
10	49392	SPACER	1	
11		ENGINE (See Note 1)	1	For Engine replacement parts on HG3500A Engine Model #170432, Type #6112-01, see your Briggs & Stratton Dealer.
12	80197	SCREW-Hex Hd. (5/16-18 X 2")	2	
13	493481	DEFLECTOR-Air	1	
14	83030	WASHER-Lock	2	
15	84110	WASHER-Flat(#10)	1	
16	46044A	SCREW (10-24 X 1 1/2")	1	
17	84032	WASHER-Flat (5/16")	2	
18	49370	GASKET-Muffler	1	
19	A49304	MUFFLER BRACKET KIT	1	
20	83009	WASHER (1/4")	12	
21	96127	STUD-Cylinder	2	
22	96212	NUT-Hex	2	
23	49421	SHIELD-Exhaust	1	
24	80044	SCREW-Hex Cap (14-20 X 1 1/8")	7	
25	82279	SCREW-Tap Pan Hd. (#8-18 X 3/8")	1	
26	49419	SHIELD-Muffler	1	
27	49372	MUFFLER	1	
28	49329	PIN-Clevis	4	
29	84006	WASHER-Flat (1/4")	4	
30	49351	GROMMET-Isolator	3	
31	49179	CAP-Fuel	1	
32	489311	FUEL TANK	1	

Ref #	Part #	Description	Qty	Context Note
33	49005	VALVE-Fuel FUEL LINE	1	
34	A49306	ASSEMBLY (See Note 2)	1	Cut fuel line to the desired length
35	A493211A	ROLL CAGE	1	
36	49340	DECAL-Fuel Valve	1	
37	49598	DECAL- Caution	1	

HGE3500A Generator UT-03623-A - Wiring Diagram



Rendered by LeadVenture, Inc.