



HH100 Portable Space Heater UT-65044 - Exploded View



Ref #	Part #	Description	Qty	Context Note
1	0053136	UPPER SHELL	1	
2	0053132	CHAMBER- Combustion	1	
3	0052919	PHOTOCELL BRACKET	1	
4	0052918	PHOTOCELL ASSEMBLY	1	
5	0053125	NOZZLE	1	
6	0053102	WASHER- Nozzle	2	
7	0053103	SPRING- Nozzle	1	
8	0053130	SLEEVE- Nozzle	1	
9	0053120	BODY- Burner head	1	
10	0053119	FITTING- Barb.	3	
11	0053104	SPARK PLUG	1	
12	0053128	FAN	1	
13	0053135	MOTOR (Split phase)	1	
14	0052953	PUMP- Body	1	
15	0052920	INSERT- Rotor	1	
16	0052921	ROTOR- Pump	1	
17	0053117	COVER- End pump	1	
18	0053106	FILTER- Intake	1	
19	0053110	COVER- End filter	1	
20	0052948	BALL- Steel 1/4 dia.	1	
21	0052909	SPRING- Relief	1	
22	0052924	SCREW- Adjusting	1	
23	0052922	PLUG	1	
24	0053107	FILTER- Output	1	
25	0053105	FILTER- Lint	1	
26	0052947	BLADE	4	
27	0053122	BRACKET- Motor Mounting	1	
28	0053133	SOLID STATE RELAY	1	
29	0052949	NUT- Lock hex	2	
30	0053124	GUARD- Fan	1	
31	0052951	IGNITOR	1	
32	0053129	FUEL LINE	1	
33	0053126	FILTER- Fuel	1	
34	0053127	FUEL LINE TUBE	1	
35	0053118	AIRLINE	1	
36	0053137	SHELL- Lower	1	
37	0052914	CLIP- Nut	6	
38	0053134	TANK- Fuel	1	
39	0052958	CAP- Fuel (includes gasket)	1	
40	0052939	CONTROL- Safety	1	
41	0053123	COVER- Side	1	

Ref #	Part #	Description	Qty	Context	Note
42	0052952	IGNITOR CABLE ASSY.	1		
43	A0052962	POWER CORD ASSY.	1		
44	0052913	BUSHING- Strain Relief	1		
45	0053141	DECAL- Fuel	1		
46	A0053139	RUBBER BUSHING & BUMPER KIT	1		
47	0053142	DECAL- Reset	1		
48	0053140	DECAL- General Info.	1		
49		SCREW- #6-32 x 3/8	1		
50		SCREW- #10-32 x 1/2	1		
51		SCREW- #10-32 x 1	1		
52		SCREW- Grounding #8-18 x 1/4	1		
53		SCREW- #10-16 x 1/2	1		
54	0053112	WHEELS	2		
55	0053121	AXLE	1		
56	0053108	FRAME SUPPORT WHEEL	1		
57	0053101	FRONT HANDLE	1		
58	0053109	MOUNTING SCREWS	8		
59	0053115	NUT CAP	2		
60	0053131	NUT- Hex Lock #10-24	8		
	0052903	HANG-UP THERMOSTAT	1		

HH100 Portable Space Heater UT-65044 - Wiring Diagram



Rendered by LeadVenture, Inc.